

Important Safety Precautions

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this user guide.

WARNING! *Violation of the instructions may cause serious injury or death.*



1. Never use an unapproved battery since this could damage the phone and/or battery and could cause the battery to explode.



2. Never place your phone in a microwave oven as it will cause the battery to explode.
3. Never store your phone in temperatures less than -4°F or greater than 122°F.
4. Do not dispose of your battery by fire or with hazardous or flammable materials.



5. When riding in a car, do not leave your phone or set up the hands-free kit near to the air bag. If wireless equipment is improperly installed and the air bag is deployed, you may be seriously injured.
6. Do not use a hand-held phone while driving.



7. Do not use the phone in areas where its use is prohibited. (For example: aircraft)

Important Safety Precautions



1. Do not expose the battery charger or adapter to direct sunlight or use it in places with high humidity, such as a bathroom.



2. Do not use harsh chemicals (such as alcohol, benzene, thinners, etc.) or detergents to clean your phone. This could cause a fire.



3. Do not drop, strike, or shake your phone severely. It may harm the internal circuit boards of the phone.



4. Do not use your phone in high explosive areas as the phone may generate sparks.
5. Do not damage the power cord by bending, twisting, pulling, or heating. Do not use the plug if it is loose as it may cause a fire or electric shock.



6. Do not place any heavy items on the power cord. Do not allow the power cord to be crimped as it may cause electric shock or fire.



7. Do not handle the phone with wet hands while it is being charged. It may cause an electric shock or seriously damage your phone.
8. Do not disassemble the phone.



9. Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.

10. Do not hold or let the antenna come in contact with your body during a call.



11. Make sure that no sharp-edged items such as animal's teeth or nails, come into contact with the battery. This could cause a fire.

12. Store the battery out of reach of children.



13. Be careful that children do not swallow any parts (such as rubber plugs, earphone, connection parts of the phone, etc.) This could cause asphyxiation or suffocation resulting in serious injury or death.



14. Unplug the power cord and charger during lightning storms to avoid electric shock or fire.

15. Only use the batteries and chargers provided by LG. The warranty will not be applied to products provided by other suppliers.



16. Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.



17. An emergency call can be made only within a service area. For an emergency call, make sure that you are within a service area and that the phone is turned on.

Table of Contents

Important Safety Precautions	1	Activate your Virgin Mobile account	14	Using Phone Menus	22
Table of Contents	4	Turning the Phone On and Off	15	Menu Access	22
Welcome	7	Turning the Phone On	15	My Stuff	22
Important Information	7	Turning the Phone Off	15	1. My ringtones	22
FCC RF Exposure Information	9	Program your Virgin Mobile phone	15	2. My graphics	23
Phone Overview	10	Signal Strength	16	3. My games	23
Menus Overview	11	Screen Icons	16	4. Available memory	23
Getting Started with Your Phone	13	Making Calls	16	My Account	23
Find your phone's serial number	13	Correcting Dialing Mistakes	16	Settings	26
The Battery	13	Redialing Calls	16	1. Display	26
Installing the Battery	13	Receiving Calls	17	1.1 Wallpaper	26
Removing the Battery	13	Quick Access to Convenient Features	18	1.2 Screensaver	26
Charging the Battery	14	Call Waiting	18	1.3 Clocks	27
Battery Charge Level	14	Caller ID	18	1.4 Incoming calls	27
		Speed Dialing	18	1.5 Greeting	27
		Entering and Editing Information	19	1.6 Menu styles	27
		Text Input	19	1.7 Font size	27
		Text Input Examples	20	1.8 Backlight	28
				1.9 Power save mode	28
				1.0 Status light	28
				1.* Contrast	28

2. Sounds	29	6.6 Reset phone	33	Messaging	40
2.1 Ringtones	29	7. Setup/Others	33	1. Send message	41
2.2 Key length	29	7.1 Answer call	33	2. Voicemail	42
2.3 Volume	29	7.2 Auto-answer	33	2.1 Call voicemail	42
2.4 Alerts	29	7.3 Voice dial	34	2.2 Voicemail details	42
3. Location	30	7.4 Dialing match	34	2.3 Clear icon	42
4. Messaging	30	7.5 TTY mode	34	3. Inbox	43
5. Text entry	30	7.6 Airplane mode	35	4. Outbox	44
5.1 Auto-capital (Enable/ Disable)	30	8. Phone info	35	5. Draft	44
5.2 Auto-space (Enable/ Disable)	30	8.1 My phone number	35	6. Saved	44
5.3 Word choice list (Enable/ Disable)	31	8.2 Version	35	7. Virgin Alerts	44
5.4 Word prediction (Enable/ Disable)	31	8.3 Icon glossary	35	8. Settings	45
5.5 Word completion (Enable/ Disable)	31	8.4 Advanced	35	8.1 Notification	45
5.6 Use my words (Enable/ Disable)	31	Contacts	36	8.2 Alerts	45
5.7 My words (Add New)	31	1. Find/Add entry	36	8.3 Auto-delete	45
5.8 Help	31	2. Groups	37	8.4 Signature	45
6. Security	31	3. Speed dials	37	8.5 Auto text	46
6.1 Lock phone	31	4. Voice dials	38	Tools	47
6.2 Change lock	32	5. Information	38	1. Scheduler	47
6.3 Special #s	32	VirginXL	39	2. Alarm clock	48
6.4 Delete contacts	32				
6.5 Selective call block	32				

Table of Contents

3. Ez tip calculator	49	Hearing Aids	55	Accessories	72
4. Calculator	49	Other Medical Devices	55		
5. World clock	49	Health Care Facilities	55		
6. Voice memo	50	Vehicles	55		
7. Notepad	50	Posted Facilities	55		
		Aircraft	55		
Recent calls	51	Blasting Areas	55		
1. Missed calls	51	Potentially Explosive Atmosphere	56		
2. Incoming calls	51	For Vehicles Equipped with an Air Bag	56		
3. Outgoing calls	52	Safety Information	56		
4. Delete history	52	Charger and Adapter Safety	56		
		Battery Information and Care	56		
Safety	53	Explosion, Shock, and Fire Hazards	57		
		General Notice	57		
TIA Safety Information	53	Avoid damage to your hearing	58		
Exposure to Radio Frequency Signal	53	FDA Consumer Update	59		
Antenna Care	53	10 Driver Safety Tips	66		
Phone Operation	53	Consumer Information on SAR	68		
Tips on Efficient Operation	54	FCC Hearing-Aid Compatibility (HAC) Regulations for Wireless Devices	70		
Driving	54				
Electronic Devices	54				
Pacemakers	54				
Persons with pacemakers:	54				

Congratulations for choosing the advanced and compact LX140 cellular phone, designed to operate with Code Division Multiple Access (CDMA). Along with the many advanced features of the CDMA system, such as greatly enhanced voice clarity, this phone offers:

1. Large, easy-to-read, 7-line backlight LCD with status icons.
2. Paging, messaging, voicemail, and caller ID.
3. 19-key keypad.
4. Speakerphone feature.
5. Menu-driven interface with prompts for easy operation and configuration.
6. Any key answer, auto answer, auto retry, one-touch and speed dialing with 99 memory locations.

Important Information

This user's guide provides important information on the use and operation of your phone. Please read all the information carefully prior to using the phone for the best performance and to prevent any damage to or misuse of the phone. Any unapproved changes or modifications will void your warranty.

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device and its accessories may not cause harmful interference, and (2) This device and its accessories must accept any interference received, including interference that causes undesired operation.

Technical Details

The LX140 is a PCS only phone that operates on Code Division Multiple Access (CDMA) frequencies: cellular services at 1900 Mhz.

Welcome

CDMA technology uses a feature called DSSS (Direct Sequence Spread Spectrum) that enables the phone to keep communication from being crossed and to use one frequency channel by multiple users in the same specific area. This results in a 10-fold capacity increase when compared with analog mode. In addition, features such as soft / softer handoff, hard Handoff, and dynamic RF power control technologies combine to reduce call interruptions.

The Cellular and PCS CDMA networks consist of MSO (Mobile Switching Office), BSC (Base Station Controller), BTS (Base Station Transmission System), and MS (Mobile Station). The following table lists some major CDMA standards.

* TSB-74: Protocol between an IS-95A system and ANSI J-STD-008

1xRTT system receives twice as many subscribers in the wireless section as IS-95. Its battery life is twice as long as IS-95. High-speed data transmission is also possible.

CDMA Standard	Designator	Description
Basic Air Interface	ANSI J-STD-008	IS-95 adapted for PCS frequency band
	TIA/EIA-IS2000	cdma2000 1xRTT AirInterface
Network	TIA/EIA/IS-634	MAS-BS
	TIA/EIA/IS/651	PCSC-RS
	TIA/EIA/IS-41-C	Intersystem operations
	TIA/EIA/IS-124	Non-signaling data comm.
Service	TIA/EIA/IS-96-B	Speech CODEC
	TIA/EIA/IS-637	Short message service
	TIA/EIA/IS-657	Packet Data
	IS-801	Position Determination Service (gpsOne)
Performance	TIA/EIA/IS-97	Cellular base station
	TIA/EIA/IS-98	Cellular mobile station
	ANSI J-STD-018	PCS personal station
	ANSI J-STD-019	PCS base station
	TIA/EIA/IS-125	Speech CODEC

FCC RF Exposure Information

WARNING! *Read this information before operating the phone.*

In August 1996, the Federal Communications Commission (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to Radio Frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies.

The design of this phone complies with the FCC guidelines and these international standards.

Bodily Contact During Operation

This device was tested for typical use with the back of the phone kept 0.6 inches (1.5 cm) from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 0.6 inches (1.5 cm) must be maintained between the user's body and the back of the phone, including the antenna, whether extended or retracted. Third-party belt-clips, holsters and similar accessories containing metallic

components should not be used. Avoid the use of accessories that cannot maintain 0.6 inches (1.5 cm) distance between the user's body and the back of the phone and have not been tested for compliance with FCC RF exposure limits.

Vehicle-Mounted External Antenna

(Optional, if available.)

A minimum separation distance of 8 inches (20 cm) must be maintained between the user / bystander and the vehicle-mounted external antenna to satisfy FCC RF exposure requirements. For more information about RF exposure, visit the FCC website at www.fcc.gov.

Caution

Use only the supplied and approved antenna. Use of unauthorized antennas or modifications could impair call quality, damage the phone, void your warranty and/or result in violation of FCC and IC regulations.

Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin a minor burn may result. Contact your local dealer for a replacement antenna.

Phone Overview



- 1 Earpiece**
- 2 Flip** Open the case to answer an incoming call.
- 3 LCD Screen** Displays messages and indicator icons.
- 4 Headset Jack**
- 5 Left option button** Use to display the function setting menu.
- 6 SEND Key** Use to place or answer calls.
- 7 Navigation Keys** Use for quick access to Messages, Recent Calls, My Account and VirginXL.
- 8 Right option button** Use to select an action within a menu.
- 9 OK/Menu Key** Use to displays the phone's main menu from standby mode. It also selects the highlighted choice when navigating through a menu.
- 10 END/PWR Key** Use to turn the power on/off and to end a call. Also use to return to the standby display screen.
- 11 BACK Key** Pressing BACK key will return you to the previous menu. Text Messaging: press to delete a single space or character. Press and hold to delete entire words.
- 12 Alphanumeric Keypad** Use to enter numbers and characters and select menu items.
- 13 Microphone**

Note Shortcut to "Vibrate All" by pressing and holding .

Menus Overview

1. My Stuff

1. My ringtones
 2. My graphics
 3. My games
 4. Available memory
-

2. My Account

1. Launch
-

3. Settings

1. Display
 1. Wallpaper
 2. Screensaver
 3. Clocks
 4. Incoming calls
 5. Greeting
 6. Menu styles
 7. Font size
 8. Backlight
-

9. Power save mode
 0. Status light
 - *. Contrast
 2. Sounds
 1. Ringtones
 2. Key length
 3. Volume
 4. Alerts
 3. Location
 4. Messaging
 1. Notification
 2. Alerts
 3. Auto-delete
 4. Signature
 5. Auto text
-

5. Text entry
 1. Auto-capital
 2. Auto-space
 3. Word choice list
 4. Word prediction
 5. Word completion
 6. Use my words
 7. My words
 8. Help
 6. Security
 1. Lock phone
 2. Change lock
 3. Special #s
 4. Delete contacts
 5. Selective call block
 6. Reset phone
-

7. Setup/Others
 1. Answer call
 2. Auto-answer
 3. Voice dial
 4. Dialing match
 5. TTY mode
 6. Airplane mode
 8. Phone info
 1. My phone number
 2. Version
 3. Icon glossary
 4. Advanced
-

Menus Overview

4. Contacts

1. Find/Add entry
2. Groups
3. Speed dials
4. Voice dials
5. Information

5. VirginXL

1. Launch

6. Messaging

1. Send message
2. Voicemail
 1. Call voicemail
 2. Voicemail details
 3. Clear icon
3. Inbox
4. Outbox
5. Draft
6. Saved
7. Virgin Alerts
8. Settings
 1. Notification
 2. Alerts
 3. Auto-delete
 4. Signature
 5. Auto text

7. Tools

1. Scheduler
2. Alarm clock
 1. Alarm 1
 2. Alarm 2
 3. Alarm 3
 4. Quick alarm
3. Ez tip calculator
4. Calculator
5. World clock
6. Voice memo
7. Notepad

8. Recent calls

1. Missed calls
2. Incoming calls
3. Outgoing calls
4. Delete history
 1. Missed calls
 2. Incoming calls
 3. Outgoing calls
4. All calls

Note

Shortcuts in this guide may not line up while in List View.

Getting Started with Your Phone

Find your phone's serial number

You can check information as follows:

Menu > Settings > Phone info > My phone number.

The serial number is next to the words MEID DEC. It has 18 digits. Write down the serial number.

Note

You can also find your serial number (MEID DEC) on the label underneath the battery.

The Battery

Note

It is important to fully charge the battery before initial use of the phone.

The phone comes with a rechargeable battery. Keep the battery charged while not in use in order to maximize talk and standby time. The battery charge level is shown at the top of the LCD screen.

Installing the Battery

To install the battery, insert the battery into the opening on the back of the phone. Put the battery cover on the battery and push it slightly upwards.

Removing the Battery

Turn the power off. Pull the battery cover downward and remove it. Then remove the battery by pressing the upper area of it.

Getting Started with Your Phone

Charging the Battery

To use the charger provided with your phone:

Warning! Use only the charger provided with the phone. Using any charger other than the one included with the LX140 may damage your phone or battery.

1. Plug the end of the adapter into the phone's charger port and the other end into an electrical outlet.
2. The charge time varies depending upon the battery level.

Battery Charge Level

The battery charge level is shown at the top right of the LCD screen. When the battery charge level becomes low, the low battery sensor alerts you in three ways: sounding an audible tone, blinking the battery icon, and displaying **Low Battery**. If the battery charge level becomes exceedingly low, the phone automatically switches off and any function in progress is not saved.



Activate your Virgin Mobile account

Before you can start talking, messaging, or downloading, you need to activate service with Virgin Mobile. You need your phone's serial number to activate your Virgin Mobile account (see "Find your phone's serial number" on page 13). Activate your account online by going to www.virginmobileusa.com and clicking on Activate. Or call Virgin Mobile At Your Service at 1-888-322-1122.

Turning the Phone On and Off

Turning the Phone On

1. Install a charged battery or connect the phone to an external power source such as a vehicle power charger or hands-free car kit.
2. Press  for a few seconds until the LCD screen lights up.

Note

Like any other radio device, avoid any unnecessary contact with the antenna while your phone is on.

Turning the Phone Off

1. Press and hold  until the display turns off.

Program your Virgin Mobile phone

Once your account is activated, you need to program your new Virgin Mobile phone number into your phone.

1. Turn on your phone.
2. Dial ##VIRGIN# (that's #-#-8-4-7-4-4-6-#)

3. You are now in the Programming menu. Scroll down to "Activate Phone" and hit "OK".
4. Your screen will say, "Do you want to activate your phone now ?" Select "Yes".
5. Your phone will connect to the network, and then the screen will say "Hi. Press Start to continue the activation process". Scroll down to "Start" and hit "OK".
6. Your phone will say "We're getting your phone number for you," then your phone will display your new Virgin Mobile phone number. Write it down.
7. Scroll down to "Finish" and hit "OK" to complete the activation process. Your phone will turn off and back on by itself.

That's it, you're done! It might take a couple of hours to get you set up on our network, but we will send a text message to your phone to let you know you can start talking. Also, it may take up to 4 hours for VirginXL, Voicemail, and Top-Up features to come online.

Getting Started with Your Phone

Signal Strength

Call quality depends on the signal strength in your area. The signal strength is indicated on the screen as the number of bars next to the signal strength icon: The more bars, the better the signal strength. If the signal quality is poor, move to an open area. If you are in a building, the reception may be better near a window.

Screen Icons

When the phone is powered on, the top line of the LCD screen displays icons indicating the status of the phone.

To see the icons, go to **Menu -> Settings -> Phone info -> Icon glossary**.

Making Calls

1. Make sure the phone is turned on. If not, press  for about 3 seconds.
2. Enter the phone number (include the area code if needed).
3. Press .
4. Press  to end the call.

Correcting Dialing Mistakes

If you make a mistake while dialing a number, press  once to erase the last digit entered or hold down  for at least 2 seconds to delete all digits.

Redialing Calls

1. Press  twice to redial the last number you dialed. The last 50 numbers are stored in the call history list and you can also select one of these to redial.

Receiving Calls

1. When the phone rings or vibrates press  to answer.

Note

If you press  while the phone is ringing, the ringing or vibration is muted for that call.

2. Press  twice to end the call.

Quick Access to Convenient Features

Call Waiting

Your cellular service may offer call waiting. While a call is in progress, two beeps indicate another incoming call. When call waiting is enabled, you may put the active call on hold while you answer the other incoming call.

1. Press  to receive a waiting call.
2. Press  again to switch between calls.

Caller ID

Caller ID displays the phone number or name of the incoming call. If the caller's identity is stored in Contacts, the name appears with the number.

Speed Dialing

Speed dialing is a convenient feature that allows you to make phone calls quickly and easily with a few keystrokes. Your phone recalls the number from your Contacts, displays it briefly, and then dials it. Speed Dial Number 1 is assigned to voicemail by default.

Dialing Single Digit Speed Dials (from 1 to 9)

Press and hold the Speed Dial number.

OR

Enter the Speed Dial number and press .

Dialing Double Digit Speed Dials (from 10 to 99)

Press the first digit and then press and hold the key of the last digit.

OR

Enter the first and second digits and press .

Entering and Editing Information

Text Input

Text Input Modes

There are five modes for entering text, numbers, special characters, and punctuation. In a text entry field, pressing right option button  displays a pop-up list of text modes.

Key Functions



Right option button : Press to scroll through the following text input modes:

T9Word -> Abc -> 123 -> Symbols -> Smileys



Shift : Press to change case.

T9 text : T9Word -> T9WORD -> T9word

Abc text : Abc -> ABC -> abc



Next : In T9 mode, press to display other matching words.



Space : Press to complete a word and insert a space.



BACK : Press to delete a single space or character. Hold to delete words.



Punctuation : In T9 mode, press to insert punctuation in a word and complete a sentence.

T9Word (T9) Mode

Use to type text using one keystroke per letter. The phone translates keystrokes into common words by using the letters on each key and a compressed database.

Abc (Multi-tap) Mode

Use to add words to the T9 database.

123 (Numbers) Mode

Use to type numbers using one keystroke per number.

Symbols Mode

Use to insert special characters or punctuation. There are 35 special characters including "SP" which inserts a space and "LF" which forces the text to the next line.

Smileys Mode

Use to insert smiley graphics. There are 36 smiley characters.

Entering and Editing Information

Changing Letter Case

Using T9 and Abc text input modes you can set the capitalization. Press  to cycle through the following.

Initial Cap (T9Word / Abc)

Only the first letter is capitalized. All subsequent letters are lower case.

Caps Lock (T9WORD / ABC)

All letters are capitalized.

Lower Case (T9word / abc)

All letters are in lower case.

Text Input Examples

Display the text modes and select a text mode:

1. In a text entry field, press right option button  to display text modes.
2. Press  to highlight the text input mode you want to use.
3. Press  to select the highlighted text input mode.

Using Abc (Multi-tap) Text Input

1. Press right option button  to change to Abc mode.
2. Press  to change to ABC Caps Lock.
3. Press     .
LG is displayed.

Using T9 Mode Text Input

1. Press right option button  to change to T9Word mode.
2. Press **2**abc **2**abc **5** jkl **5** jkl .
3. Press **#**^{space} to complete the word and add a space.
4. Press **8**tuv **4** ghi **3** def **#**^{space} **6**mno **3** def **3** def **4** ghi **2**abc **3** def .

Call the office is displayed.

Using the NEXT Key

After you have finished entering a word, if the word displayed is not the one you want, press **0**^{+next} to display additional choices of words from the database.

1. Press **4** ghi **6**mno **6**mno **3** def .
Good is displayed.
2. Press **0**^{+next} .

The display gives you additional choices such as:
Home, Gone, Hood, etc.

Adding Words to the T9 Database

If a word is not in the T9 database, add it by using Abc (Multi-tap) mode text entry.

1. Press right option button  to change to Abc (Multi-tap) mode.
2. Press **2**abc **2**abc **6**mno **6**mno **6**mno **7**pqrs .
Bop is displayed.
3. Press right option button  to change to T9 mode to add the word **Bop** to the T9 database.
4. Press **BACK** to erase the existing word.
5. Press **2**abc **6**mno **7**pqrs . Select **Bop**.

Menu Access

Press **OK** or left option button  to have access to 8 phone menus. There are two methods to access menus and submenus:

- Use the navigation key to highlight and select, or
- Press the number key that corresponds to the menu or submenu.

For example:

1. Press **OK**.
Eight menu items are displayed.
Use  to scroll through the list of menus.
2. Press the appropriate number key corresponding to the menu item you want to select.
The sub-menu list will be displayed.
3. Press the appropriate number key corresponding to the sub-menu you want to access.
4. Use  to highlight your preferred setting and press **OK** to select it.

Note

Press **BACK** to go back one step (while accessing a menu or selecting a setting). Changes to settings will not be saved.

My Stuff

My stuff lets you preview, assign & download graphics, ringtones, and more. Charges apply for most downloads. Additional charges may apply for multiple balance checks in one day. See www.virginmobileusa.com for pricing details.

Access and Options



1. Press **OK** **Menu**.
2. Press **1** **My Stuff**.
3. Select a sub-menu.



1. **My ringtones**
2. **My graphics**
3. **My games**
4. **Available memory**

1. My ringtones

The My ringtones folder stores your preloaded and downloaded ringtones. You can download the latest ringtones at www.virginmobileusa.com or directly from your phone using VirginXL.

1. Press **OK**, **1**, **1**.
2. Highlight **Get more ringtones** and press **OK** (The browser will launch and take you to the Ringers download menu).

2. My graphics

The My graphics folder stores your downloaded graphics. Download the latest wallpapers at www.virginmobileusa.com or directly from your phone using VirginXL.

1. Press **OK**, **1**, **2abc**.
2. Highlight **Get more graphics** and press **OK** (The browser will launch and take you to the Screen Savers download menu).

3. My games

You can play some preloaded games available on your phone.

1. Press **OK**, **1**, **3def**.
2. Use **↵** to select a game, then press **OK**.
ZooZooClub/ Battle reversi


4. Available memory

1. Press **OK**, **1**, **4ghl**.

My Account

The My Account menu allows you to manage your Virgin Mobile services. Check your balance and Top-Up here.

Access and Options



1. Press **OK**.
2. Press **2abc** **My Account** or Press **↵** in standby mode.

Top-Up

Top-Up is how you add money to your Virgin Mobile account. You can Top-Up your Virgin Mobile account right from your phone. First, buy a Top-Up card at the thousands of retailers that carry them; or register your debit card, credit card, or Paypal account at

My Account

www.virginmobileusa.com

When your balance is low, you can Top-Up your account from your phone.

Top-Up with a Top-Up card

1. Press the left option button to select "Menu".
2. Using the Navigation key, scroll to "VirginXL" and press .
3. Scroll down and select the "Top-Up" link and press .

Note

You can tell it's selected because it's highlighted.

4. Top-Up Card is highlighted so press .
5. Enter your vKey and press .
6. Scroll down to select "Login" and press .
7. Enter your Top-Up card's pin number and press .

8. Scroll down to select "Top-Up Now" and press .
9. At the confirmation screen, select "Yes" by pressing .
10. At the "Approved" screen scroll to OK and press the  button.
11. Hit the red phone key to exit.

Top-Up with a Debit Card, Credit Card, or Paypal account

Before you can Top-Up from your phone with a debit card, credit card, or Paypal account, you need to register the card or Paypal account at www.virginmobileusa.com.

1. Press the left option button to select "Menu".
2. Using the Navigation key, scroll to "VirginXL" and press .
3. Scroll down and select the "Top-Up" link and press .

Note

You can tell it's selected because it's highlighted.

4. Scroll down and select "Credit Card" and press .
5. Enter your vKey and press .
6. Scroll down to select "Login" and press .
7. Enter the amount for Top-Up and press .
8. Scroll down to select "Top-Up Now" and press .
9. Your handset will validate the amount you want to Top-Up. Scroll down to select "Yes" and press .
10. That's it. Your phone will announce that "You're Topped-Up." Press .
11. Hit the red phone key to exit.

You can also Top-Up on the web at www.virginmobileusa.com.

Settings

Settings

The Settings Menu has options to customize your phone.

Access and Options



1. Press **OK** **Menu**.
2. Press **3 def** **Settings**.
3. Select a sub-menu.



1. **Display**
2. **Sounds**
3. **Location**
4. **Messaging**
5. **Text entry**
6. **Security**
7. **Setup/Others**
8. **Phone info**

1. Display

Provides you with options to customize the phone's display screen.

1.1 Wallpaper

Allows you to choose the kind of background to be displayed on the phone.

1. Press **OK**, **3 def**, **1 ex**, **1 ex**.
2. Select **Preloaded/ Downloaded**, then press **OK**.
3. Select from different screens, then press **OK**.
4. Press left option button **Assign**.

1.2 Screensaver

Allows you to choose the kind of Screensavers to be displayed on your phone while not in use.

1. Press **OK**, **3 def**, **1 ex**, **2 abc**.
2. Select **On**, then press **OK**.
3. Select **Preloaded/ Downloaded**, then press **OK**.
4. Select from different screens, then press **OK**.

5. Press left option button  **Assign**.

1.3 Clocks

Allows you to choose the kind of clock to be displayed on the LCD screen.

1. Press , **3**^{def}, **1**[☒], **3**^{def}.
2. Select an option.
Normal clock/ Analog clock/ Digital clock/ Dual clock
3. Press .

1.4 Incoming calls

Allows you to set a specific screen for incoming calls.

1. Press , **3**^{def}, **1**[☒], **4**^{ghi}.
2. Select **Caller ID/ No caller ID**.
3. For each selection, choose a setting.
Preloaded/ Downloaded
4. Among the choices, select your favorite and press  twice.

1.5 Greeting

Allows you to enter a string of greeting up to 16 characters displayed on the LCD screen.

1. Press , **3**^{def}, **1**[☒], **5**^{jkl}.
2. Select a setting.
Custom/ Off
3. If you set to **Custom** enter your greeting words and press .

1.6 Menu styles

Allows you to view the Menu as Grid or List.

1. Press , **3**^{def}, **1**[☒], **6**^{mno}.
2. Select **Grid** or **List**.

1.7 Font size

Allows you to set the size of the font for Message, Browser and Notepad.

1. Press , **3**^{def}, **1**[☒], **7**^{pqrs}.
2. Select the menu to set the font size.
Message/ Browser/ Notepad

Settings

3. Select a font size.
Small/ Medium/ Large

1.8 Backlight

Allows you to set the duration for illuminating the backlight. Main LCD and Keypad are set separately.

Note

If an amount of time is set for the timer option, the time starts after the last key was pressed.

1.8.1 Display

1. Press **OK**, **3 def**, **1 []**, **8 tuv**, **1 []**.
2. Choose a sub-menu, then press **OK**.

Dim only/ 8 seconds/ 15 seconds/ Flip open

1.8.2 Keypad

1. Press **OK**, **3 def**, **1 []**, **8 tuv**, **2 abc**.
2. Choose a sub menu and then press **OK**.

Always off/ 8 seconds/ 15 seconds/ 30 seconds

1.9 Power save mode

Display and buttons are lit for a designated length of time, allowing your convenience to use your phone in the dark.

1. Press **OK**, **3 def**, **1 []**, **9 wxyz**.
2. Use **[]** to select **Off/ 30 seconds/ 60 seconds/ 90 seconds**, then press **OK**.

1.0 Status light

Shows the status on your phone by blinking the light.

1. Press **OK**, **3 def**, **1 []**, **0 +next**.
2. Use **[]** to set to **On** or **Off**, then press **OK**.

1.* Contrast

Allows you to set the level of contrast for your LCD screen.

1. Press **OK**, **3 def**, **1 []**, ***_shift**.
2. Use **[]** to adjust the level.

2. Sounds

Provides options to customize the phone's sounds.

2.1 Ringtones

You can assign a ringer type to a contact entry so you can identify the caller by the ringer type. In Settings > Sound > Ringtone, you can only customize Caller ID & No caller ID.

1. Press **OK**, **3 def**, **2 abc**, **1 ☒**.
2. Select **Caller ID/ No caller ID**.
3. Select **Preloaded/ Downloaded**.
4. Use **5 sp** to select a ringer, then press **OK**.

To set a custom ringtone for individual contacts:

1. From standby mode, press **Contacts** (right softkey).
2. Select the entry for which you want to set the incoming ringer and press **OK**.
3. Scroll down to the **<Edit entry>** and press **OK**.
4. Scroll down to the box of ringer icon and press **OK**.
And select **Preloaded / Downloaded**.

5. Select the desired ringtone and press **Assign** (left softkey).
6. Press **Done** (left softkey) to save the ringer type.

2.2 Key length

Allows you to select the key length type.

1. Press **OK**, **3 def**, **2 abc**, **2 abc**.
2. Select a tone style, then press **OK**.
Short tones/ Long tones

2.3 Volume

Allows you to set various volume settings.

1. Press **OK**, **3 def**, **2 abc**, **3 def**.
2. Select **Ringtone/ Earpiece/ Key beep/ Game/ Power On/Off**.
3. Use **1 m** to adjust the volume of the ringer, then press **OK**.

2.4 Alerts

Allows you to select the alert type just in cases of new Voicemail alerts, Message alerts, Missed call

alerts, Service change, Minute beep, Call connect, Signal fade, Reminder.

1. Press **OK**, **3 def**, **2 abc**, **4 ghi**.
2. Select **Voicemail alerts/ Message alerts/ Missed call alerts/ Service change/ Minute beep/ Call connect/ Signal fade/ Reminder**.
3. Use **S** to select a setting, then press **OK**.

**Voicemail alerts/ Message alerts/
Missed call alerts : Preloaded/ Downloaded**

**Service change/ Minute beep/ Call connect/
Signal fade/ Reminder : On/ Off**

3. Location

Menu for GPS (Global Positioning System: Satellite assisted location information system) mode.

1. Press **OK**, **3 def**, **3 def**.
The Location disclaimer is displayed.
2. Read the disclaimer and press **OK**.
3. Use **S** to select a setting, then press **OK**.
On/ Off

Note

GPS satellite signals are not always transmitted, especially under bad atmospheric and environmental conditions, indoors etc.

4. Messaging

Allows you to configure 5 settings for messages.

See **Settings** on page 45.

5. Text entry

Allows you to configure 8 settings for received messages.

1. Press **OK**, **3 def**, **5 jkl**.
2. Use **S** to highlight one of the settings and press **OK** to select it.

5.1 Auto-capital (Enable/ Disable)

Allows you to automatically capitalize letters when necessary.

5.2 Auto-space (Enable/ Disable)

Allows you to give space between letters or words as necessary.

5.3 Word choice list (Enable/ Disable)

Allows you to view the list of recommended word choices while entering a message.

5.4 Word prediction (Enable/ Disable)

Allows you to set your phone to predicting words when you enter a word in writing a message.

5.5 Word completion (Enable/ Disable)

Allows you to complete word when you enter a word in writing a message.

5.6 Use my words (Enable/ Disable)

Allows you to get word recommendations from your word database.

5.7 My words (Add new)

Allows you to store your words for future use as a kind of database.

5.8 Help

Shows you the usefulness of modifying word options for your convenience.

6. Security

The Security Menu allows you to secure the phone electronically.

6.1 Lock phone

Keeps your phone from unauthorized use. Once the phone is locked, it is in restricted mode until the lock code is entered. You can receive phone calls and still make emergency calls.

You can modify the lock code using the New Lock code within the Security menu.

IMPORTANT: Be sure to write down your lock code if you change it. Virgin Mobile cannot unlock your phone for you if you forget your lock code.

1. Press  ,  ,  .

2. Enter the four-digit lock code.

The default lock code is commonly the last 4 digits of your phone number.

3. Press   **Lock phone.**

4. Use  to select an option, then press  .

Settings

- Unlock** The phone is never locked (Lock mode can be used).
- Lock now** The phone is always locked. When locked, you can receive incoming calls and make only emergency calls.
- On power up** The phone is locked when it is turned on.

6.2 Change lock

Allows you to change your lock code. To enter this menu, you're asked to enter a new lock code and once again to confirm it.

IMPORTANT: Be sure to write down your lock code if you change it. Virgin Mobile cannot unlock your phone for you if you forget your lock code.

1. Press **OK**, **3**^{def}, **6**^{mno}.
2. Enter the four-digit lock code.
3. Press **2**^{abc} **Change lock**.
4. Enter a new lock code.
5. Enter the new lock code once more to confirm it.

6.3 Special #s

Allows you to set special phone numbers.

1. Press **OK**, **3**^{def}, **6**^{mno}.
2. Enter the four-digit lock code.
3. Press **3**^{def} **Special #s**.
4. Select a location for your entry.
5. Enter a phone number then press **OK**.

6.4 Delete contacts

Allows you to erase all of your Contacts at once.

1. Press **OK**, **3**^{def}, **6**^{mno}.
2. Enter the four-digit lock code.
3. Press **4**^{ghi} **Delete contacts**.
4. In a pop up message, select **Yes/No**.

6.5 Selective call block

Allows you to block calls selectively.

1. Press **OK**, **3**^{def}, **6**^{mno}.

2. Enter the four-digit lock code.
3. Press **5** ijkl **Selective call block**.
4. Highlight **Empty** and enter a phone number you want to block.
5. Press **OK**.

IMPORTANT: When enabled, sending voice mail or SMS to call block number is available.

6.6 Reset phone

Allows you to reset your phone to the factory default settings.

1. Press **OK**, **3** def, **6** mno.
2. Enter the four-digit lock code.
3. Press **6** mno **Reset phone**.
4. Press **OK**.
5. Press **1** ☒ **Yes**.

7. Setup/Others

The Setup/Others Menu allows you to designate how the phone handles both incoming and outgoing calls.

7.1 Answer call

Allows you to determine how to answer a call.

1. Press **OK**, **3** def, **7** pqrs, **1** ☒.
2. Use **Ⓢ** um to select a setting, then press **OK**.
Flip open / TALK only

7.2 Auto-answer

Allows you to automatically answer a call. This feature is intended for use with hands free devices, but is an independent feature of the phone and must be manually turned on/off when connected or disconnected from the device.

1. Press **OK**, **3** def, **7** pqrs, **2** abc.
2. Use **Ⓢ** um to select a setting, then press **OK**.
● **Off**

Settings

- **Headset** When your phone is connected to a headset, the phone automatically responds to a call.

7.3 Voice dial

The Voice dial menu provides access to the voice services available with your phone.

1. Press **OK**, **3 def**, **7pqrs**, **3 def**.

7.3.1 Activate

Allows you to set the command to enable voice dialing.

1. Press **OK**, **3 def**, **7pqrs**, **3 def**, **1 es**.
2. Select **Talk key/Flip open/Disable** then press **OK**.

7.3.2 Train words

1. Press **OK**, **3 def**, **7pqrs**, **3 def**, **2 abc**.
2. Select **Yes/No** then press **OK**.
3. Select **Train/Un-train** then press **OK**.

7.4 Dialing match

Your dialing match options allow you to enable or disable Abbreviated dialing and Speed dialing.

1. Press **OK**, **3 def**, **7pqrs**, **4 ghi**.
2. Select **Abbreviated dialing, Contacts match, or Speed dial** and press **OK**.
3. Select **Enable or Disable** and press **OK**.
4. (Abbreviated dialing only.) If you enable Abbreviated dialing, enter a five- or six-digit number (for example, area code and prefix) and press **OK**.

7.5 TTY mode

Allows you to attach a TTY (Teletype Writer) device enabling you to communicate with parties also using a TTY device. A phone with TTY support is able to translate typed characters to voice. Voice can also be translated into characters and then displayed on the TTY.

1. Press **OK**, **3 def**, **7pqrs**, **5 jkl**.

2. Press **OK**.
3. Use **5** to select a setting, then press **OK**.

Enable/ Disable

7.6 Airplane mode

Airplane mode allows you to use many of your phone's features, such as My games, Notepad, Voice memo, etc., when you are in an airplane or in any other area where making or receiving calls or data is prohibited. When your phone is in Airplane mode, it cannot send or receive any calls or access online information.

1. Press **OK**, **3** def, **7** pars, **6** mno.
2. Press **OK**.
3. Use **5** to select a setting, then press **OK**.

On/ Off

8. Phone info

The Phone info Menu provides you with specific information pertaining to your phone model.

8.1 My phone number

Allows you to view your phone number and MEID, ESN.

1. Press **OK**, **3** def, **8** tuv, **1** es.

8.2 Version

Allows you to view the Username, versions of S/W, H/W, PRL and Browser.

1. Press **OK**, **3** def, **8** tuv, **2** abc.

8.3 Icon glossary

Allows you to view all the icons and their meanings.

1. Press **OK**, **3** def, **8** tuv, **3** def.

8.4 Advanced

Allows you to show the information of SID, Channel, Technology and Frequency.

1. Press **OK**, **3** def, **8** tuv, **4** ghi.

Contacts

The Contacts Menu allows you to store names, phone numbers and other information in your phone's memory. When you access your Contacts, the number in parentheses represents the number of entries you have stored (up to 500).

Access and Options



1. Press **Menu**.
2. Press **4 ghl** **Contacts**.
3. Select a sub-menu.



1. **Find/Add entry**
2. **Groups**
3. **Speed dials**
4. **Voice dials**
5. **Information**

1. Find/Add entry

Your phone can store up to 500 Contacts entries. Contacts entries can store up to a total of five phone numbers, and each entry's name can contain 32 characters.

1. Press **OK**, **4 ghl**, **1**.
2. Scroll to **<New entry>** and press **OK**.
3. Enter a name for the new entry and press **OK**.
4. Scroll to **[Add number]**, enter the phone number, and then press **OK**.
5. Scroll down to additional fields and enter or edit information as desired.
6. Press left option button **Done**.

To Find Contacts Entries by Name:

1. Press **OK**, **4 ghl**, **1**.
2. Scroll through all the entries using your navigation key.
Or enter the full letter of a name or part of a name.

- To display an entry, highlight it and press **OK**.
- To dial the entry's default phone number, press .
Or to display additional Contacts entries, press .

To select a ringer type for an entry:

- From standby mode, press **Contacts** (right softkey).
- Select the entry for which you want to set the incoming ringer and press **OK**.
- Scroll down to the **<Edit entry>** and press **OK**.
- Scroll down to the box of ringer icon and press **OK**.
And select **Preloaded / Downloaded**.
- Select the desired ringtone and press **Assign** (left softkey).
- Press **Done** (left softkey) to save the ringer type.

2. Groups

Allows you to view your grouped Contacts, add a new group, change the name of a group, or delete a whole group.

- Press **OK**, **4 ghl**, **2 abc**.
- Options from here:
 - Use  to highlight a group to view, then press **OK**.
 - Select **<Add group>** to add a new group to the list.
 - Use  to highlight a group, then press **OK** to change the name of the group or delete the group.
<Add members>/ <Edit group>/ <Delete group>

3. Speed dials

Allows you to view your Speed dials list, designate new Speed dials, or remove Speed dial designations entered in your Contacts.

- Press **OK**, **4 ghl**, **3 def**.
- Use  to highlight the Speed dial position (or enter the Speed dial digit), then press **OK**.

Contacts

3. Highlight **Set speed dial** and press **OK**.
 4. Use **5** to highlight the entry, then press **OK**.
A confirmation message is displayed.
- Options to choose one:

**Set speed dial/ Next empty/ Delete speed dial/
Delete all**

Note

Speed Dial #1 is predetermined for Voicemail.

4. Voice dials

Allows you to view the list of numbers programmed with voice dialing or add a Voice dial command to a number stored in your Contacts.

1. Press **OK**, **4 ghi**, **4 ghi**.
2. Scroll to **<Record new>** and press **OK**.
3. Enter or highlight the entry (name) in the Contacts and press **OK**.
4. After you are prompted to say the name you wish to program, wait for the beep and then say the

name into your phone's microphone.

5. Respond to the prompt by repeating the name after the beep.

Note

Recordings should be made in a normal use position (speaker by your ear and microphone near your mouth) while using a clear voice. Hands-free car kits or headsets should be used if the phone is primarily used with them.

5. Information

1. Press **OK**, **4 ghi**, **5 jkl**.

VirginXL

Accessing VirginXL

With VirginXL, you can access a variety of music, entertainment, and information services from your phone. Check Virgin Mobile's Web site at www.virginmobileusa.com for availability and pricing, or check directly from your phone through the VirginXL menu. Charges apply.

Access and Options



1. Press .
 2. Select **VirginXL** or press .
- Or you can access directly by pressing .

Here are just a few of the things that you can do with VirginXL on your phone:

- Download ringtones and graphics
- Meet new people & chat with friends
- Sign up for text alerts
- Surf the Web

Ending VirginXL Session

You can end a VirginXL session by pressing .

Navigating through the Browser

While using VirginXL, you will find the following:

- Numbered options (some options may not be numbered);
- Links (embedded in content);
- Text or numeric input;
- Simple text;

You can act on the options or the links by using the option buttons.

Messaging

Messaging

Access and Options



1. Press .
2. Press **Messaging**.
Or you can send message directly by pressing .
3. Select a sub-menu.



1. **Send message**
2. **Voicemail**
3. **Inbox**
4. **Outbox**
5. **Draft**
6. **Saved**
7. **Virgin Alerts**
8. **Settings**

Text messages, pages, and the voicemail box become available as soon as the phone is powered on.

- Make a call to the callback number by pressing during an Inbox message check.
- Read and edit messages saved in the outbox after

transmission and resend them.

The phone can store up to 215 messages (For example, 50 inbox text messages, 50 outbox text messages, 15 drft text messages, 50 saved text messages, 50 virgin alert messages). The information stored in the message is determined by phone model and service capability. Other limits to available characters per message may exist. Please check with your service provider for system features and capabilities.

New Message Alert

There are three ways your phone alerts you to new messages.

1. The phone displays a message on the screen.
2. One of ring types is heard, if selected.
3. The message icon () is displayed on the screen. In case of an urgent message, the icon will flash and Urgent message is displayed.

Note

If you receive the same message twice, your phone deletes the older one and the new one is stored as a Duplicate.

1. Send message

Allows you to send text messages, pages, and e-mail transmissions. Each message has a destination (up to 10 recipients per message) and information (Message). These are dependent upon the type of message you want to send.

Sending a Text Message

1. Press , ,  OR

Press .

2. Enter the recipient's address, then press .

Or press right option button  **Options** to select **From contacts/ From group/ Recent list/ Delete** and press .

Press left option button  **Next** to access the message screen.

3. Type your message (text or e-mail), then press .

Using Text Input Modes

right option button () To choose Abc/ T9Word/ 123/ Symbols/ Smileys/ Auto text/ Recent messages/ Preset suffix/ Add recipient

SHIFT Key		To change cases.
SPACE Key		To insert a space.
BACK Key		To backspace and hold it to delete words.
Punctuation Key		To insert punctuation in a word or to complete a sentence in T9 Mode.

4. Press left option button  **Send**.
A confirmation message is displayed.

Messaging

Message Icon Reference

 Voicemail	 Virgin alert read
 MULTI MSGS	 Virgin alert unread
 SMS CANCEL	 Virgin alert
 SMS DUPLICATE	
 SMS DUPLICATE LOCK	
 SMS FAIL	
 SMS PEND	
 SMS READ	
 SMS SENT	
 SMS UNREAD	
 SMS WP READ	
 SMS WP UNREAD	

2. Voicemail

Allows you to view new voice messages recorded in the voicemail box. Your phone will alert you when you receive a new voice message.

2.1 Call voicemail

Checking your voicemail box.

1. Press and hold  .

2.2 Voicemail details

1. Press  ,  ,  ,  .

2.3 Clear icon

1. Press  ,  ,  ,  .

3. Inbox

1. Press , , .

The phone alerts you in 3 ways when you receive a new message by:

- Displaying a message notification on the screen.
- Sounding a beep, vibrating or sound, if set.
- Displaying the message icon .

Received text messages and page messages may be searched and the contents viewed. Received messages are displayed from newest to oldest.

Out of Memory Warning

If the memory is full, no more messages can be received until enough memory space becomes available. A disclaimer is displayed and new messages are not accepted.

Viewing Your Inbox

Up to 50 received messages can be stored in the Inbox.

1. Press , , .

2. Use  to highlight an Inbox message.

- left option button  **Reply**.
- right option button  **Options**.

Options from Inbox view:

Call(Go to list)/ Lock(Unlock)/ Save/ Delete/ Delete all

3. Press .

Options from Inbox view:

1. Call (Go to list)/ 2. Forward/ 3. Save/ 4. Lock (Unlock)/ 5. Save number/ 6. Delete/ 7. Delete all

Options from Inbox(including url message) view:

1. Go / 2. Call (Go to list) / 3. Forward/ 4. Save / 5. Lock (Unlock) / 6. Save number / 7. Save URL / 8. Delete / 9. Delete all

3. Use  to highlight an Inbox message, then press .

Messaging

4. While viewing selected message the right option button  **Options** from here are **Call (Go to list)/ Forward/ Lock(Unlock)/ Save number/ Save URL/ Save Email/ Delete/ Delete all**

4. Outbox

Up to 50 sent messages can be stored in the Outbox. View lists and contents of sent messages and verify whether the transmission was successful or not.

1. Press  ,  ,  .
2. Use  to highlight an Outbox message.

- Press left option button  **Resend.**
- Press right option button  **Options.**

Options from Outbox view:

Call (Go to list)/ Lock (Unlock)/ Save/ Delete/ Delete all

3. Press  .

Options from here: left option button  **Forward.**

Options from message view:

Call (Go to list)/ Resend/ Edit/ Save /Lock(Unlock)/

Save auto text/ Compose new/ Delete/ Delete all

5. Draft

Displays draft messages.

1. Press  ,  ,  .

2. Use  to highlight a message.

- Press left option button  **Edit.**
- Press right option button  **Options.**

Send/ Compose new/ Delete/ Delete all

6. Saved

Displays saved messages.

1. Press  ,  ,  .

2. Use  to highlight a message.

7. Virgin Alerts

Free system messages provide information from time to time to let you know about your account.

1. Press  ,  ,  .

8. Settings

Allows you to configure 5 settings for messages.

1. Press , , ,

8.1 Notification

When you receive a text message, your phone notifies you by displaying an icon on your display screen. You can also choose to be notified with a larger pop-up message on your display screen.

1. Press , , , .
2. Use to select a setting, then press .

Msg & icon/ Icon only

8.2 Alerts

When new messages arrive, you can choose to have your phone notify you by playing an audible alert.

1. Press , , , .
2. Use to select a setting, then press .

Voicemail alerts/ Message alerts/ Reminder

8.3 Auto-delete

You can delete messages that you've already read whenever you like, or you can have your phone delete them automatically for you.

1. Press , , , .
2. Use to select a setting, then press .
On/ Off

8.4 Signature

Each message you send can have a customized signature to reflect your personality.

1. Press , , , .
2. Select **Custom** and press .
(If you do not wish to attach a signature to your outgoing messages, select **None**.)
3. Enter your signature and press .

Messaging

8.5 Auto text

Your phone is loaded with 20 auto text to help make sending text messages faster and easier.

1. Press , , ,  .
The list of auto text is displayed.
2. To edit or delete a auto text, highlight it and press  .
3. Scroll to the desired auto text and press  . Use  to select a setting, then press  .

Edit/ Send message/ Delete/ Delete all

To add a new auto text:

1. Press , , ,  .
2. To add a new auto text, select **<Add new>**.
3. Enter your message and press  . Your new message will be added to the beginning of the list.

Tools

Allows you to make use of various tools and applications.

Access and Options



1. Press **OK** **Menu**.
2. Press **7pqrs** **Tools**.
3. Select a sub-menu.



1. **Scheduler**
2. **Alarm clock**
3. **Ez tip calculator**
4. **Calculator**
5. **World clock**
6. **Voice memo**
7. **Notepad**

1. Scheduler

Allows you to conveniently keep and access your agenda(s). Simply store your appointments and your phone will alert you with a reminder of your appointment.

1. Press **OK**, **7pqrs**, **1**.
2. Use **←** to highlight the scheduled day.

- ←** Moves cursor to the left.
- Moves cursor to the right.
- ⏪** Moves to the previous week.
- ⏩** Moves to the next week.

3. Press left option button **⏪** **Add**.
4. Enter your schedule information including:
 - Date
 - Time Press **OK** to set specific time or press right option button **⏩** **All Day**.
 - Content
 - Recurring event
None/ Daily/ Mon-Fri/ Weekly/ Monthly/ Yearly

- When to ring the alarm reminder
**None/ On time/ 5 minutes/ 10 minutes/ 1 hour/
1 day/ 2 days**
- Which ring alarm to sound
Preloaded / Downloaded

5. Press left option button  **Save.**

When you exit without saving, you're asked to select **Return to edit/ Save and exit/ Exit** in a pop up message.

Note

Scheduler will not alert you during a call or during SMS transmission. It will sound the reminder after you exit a call.

2. Alarm clock

Allows you to set one of four alarms. The current time is displayed at the top of the screen when you select an alarm to set. At the alarm time, Alarm will be displayed on the LCD screen and the alarm will sound.

1. Press , , .
2. Select the alarm you want to edit.

Alarm 1/ Alarm 2/ Alarm 3/ Quick alarm

3. Use  to highlight the alarm time then press .
4. Set the time for alarm and press .
5. Use  to highlight **Once** (recurring setting) and press .
6. Press  to select one of the following and press .

Once/ Daily/ Mon - Fri/ Weekends

For **Quick alarm** option,
set **10 min later/ 30 min later/ 1 hour later/
3 hours later**

7. Use  to highlight a tone or an alert and press .
8. Use  to select one of the available alarm ring types and press .
9. Press left option button  **Save.**

3. Ez tip calculator

Allows you to quickly and easily calculate the amounts for a bill with the amount of the bill, the amount of the tip, and the number of people as variables.

1. Press , , .
2. Press left option button  **Reset** if necessary.
3. Press right option button  **Close** to exit this menu.

4. Calculator

Allows you to perform simple mathematical calculations. You can enter numbers up to the sixth decimal place.

1. Press , , .
2. Enter data.
 - Use  to enter plus, minus, slash and multiple calculations.
 - Press  to enter period and  to enter plus or minus.

- Press  to delete digits or symbols.
- Press left option button  **Reset** to reset the calculation.
- Press right option button  **Close** to end the calculation.

5. World clock

Allows you to determine the current time in another time zone or country.

1. Press , , .
2. Press right option button  **Cities** to move the time bar across the world map and display the date/time in that location.
3. Press left option button  **Set DST** to display Daylight Savings Time in the selected location.

6. Voice memo

Allows you to add, listen to, and erase short verbal reminders. In the entry of Voice memo, the recorded Voice memos are listed. You can select <Record new>, <Delete all>, <Memory info>.

1. Press , **7pqrs**, **6mno**.
2. Scroll to **<Record new>** and press .
3. Talk into the microphone after the tone, then press  **Stop**. The default memo title is the date and time of recording.

To Playback a Voice memo

1. Access Voice memo, highlight the Voice memo you want to hear, then press .

In the selected Voice memo, the following options are available:

- Play Play the selected Voice Memo.
Pause (Resume)/ Stop
- View details **Title/ Recorded On/ Play time**

- Edit title Edit the title of the selected Voice memo.
Save/ Mode : [Abc]/ Cancel

- Delete **Yes/ No**

7. Notepad

Allows you to add, read, edit, and erase notes to yourself.

1. Press , **7pqrs**, **7pqrs**.
2. Press  on **<Add new>** to write a new note then press  to save.

In entering a note, use text input mode with right option button  **Mode**. Also, note that word choices/ suggestions are listed and adding an word to database is asked while entering characters.

Recent calls

The Recent calls Menu is a list of the last phone numbers or Contact entries for calls you placed, accepted, or missed. It is continually updated as new numbers are added to the beginning of the list and the oldest entries are removed from the bottom of the list.

Access and Options



1. Press **OK** **Menu**.
2. Press **8 tuv** **Recent calls**.
Or you can access directly by pressing **REV**.
3. Select a sub-menu.



1. **Missed calls**
2. **Incoming calls**
3. **Outgoing calls**
4. **Delete history**

1. Missed calls

Allows you to view the list of missed calls; up to 50 entries.

1. Press **OK**, **8 tuv**, **1 ES**.
2. Use **REV** to highlight an entry, then
 - Press **OK** to view the entry.
 - Press **REV** to place a call to the number.
 - You can select from the following options:
Call/ Save (Phone book info)/ Send message/ Prepend/ Delete/ Next/ Prev

2. Incoming calls

Allows you to view the list of incoming calls; up to 50 entries.

1. Press **OK**, **8 tuv**, **2 abc**.
2. Use **REV** to highlight an entry.

Recent Calls

3. Outgoing calls

Allows you to view the list of outgoing calls; up to 50 entries.

1. Press **OK**, **8** **tuv**, **3** **def**.
2. Use **5** **opq** to highlight an entry.

4. Delete history

Allows you to erase selected call list(s).

1. Press **OK**, **8** **tuv**, **4** **ghi**.
2. Use **5** **opq** to highlight the list of calls to erase, then press **OK**.

**Missed calls/ Incoming calls/ Outgoing calls/
All calls**

3. Press **1** **xyz** **Yes**.

TIA Safety Information

The following is the complete TIA Safety Information for wireless handheld phones.

Exposure to Radio Frequency Signal

Your wireless handheld portable phone is a low power radio transmitter and receiver. When ON, it receives and sends out Radio Frequency (RF) signals.

In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for handheld wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

ANSI C95.1 (1992) *

NCRP Report 86 (1986)

ICNIRP (1996)

* American National Standards Institute; National Council on Radiation Protection and Measurements; International Commission on Non-Ionizing Radiation Protection.

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of your phone complies with the FCC guidelines (and those standards).

Antenna Care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Phone Operation

NORMAL POSITION: Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

Tips on Efficient Operation

For your phone to operate most efficiently:

Don't touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

Driving

Check the laws and regulations on the use of wireless phones in the areas where you drive and always obey them. Also, if using your phone while driving, please observe the following:

- Give full attention to driving -- driving safely is your first responsibility;
- Use hands-free operation, if available;
- Pull off the road and park before making or answering a call if driving conditions or the law require it.

Electronic Devices

Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment

may not be shielded against the RF signals from your wireless phone.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of six (6) inches be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

Persons with pacemakers:

- Should ALWAYS keep the phone more than six (6) inches from their pacemaker when the phone is turned ON;
- Should not carry the phone in a breast pocket;
- Should use the ear opposite the pacemaker to minimize the potential for interference;
- Should turn the phone OFF immediately if there is any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider (or call the customer service line to discuss alternatives).

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Health Care Facilities

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may use equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Turn your phone OFF in any facility where posted notices so require.

Aircraft

FCC regulations prohibit using your phone while in the air. Switch OFF your phone before boarding an aircraft.

Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a “blasting area” or in areas posted: “Turn off two-way radio”. Obey all signs and instructions.

Potentially Explosive Atmosphere

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always marked clearly. Potential areas may include: fueling areas (such as gasoline stations); below deck on boats; fuel or chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or particles (such as grain, dust, or metal powders); and any other area where you would normally be advised to turn off your vehicle engine.

For Vehicles Equipped with an Air Bag

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Safety Information

Please read and observe the following information for safe and proper use of your phone and to prevent damage. Also, keep the user guide in an accessible place at all times after reading it.

Caution! *Violation of the instructions may cause minor or serious damage to the product.*

Charger and Adapter Safety

- The charger and adapter are intended for indoor use only.
- Insert the battery pack charger vertically into the wall power socket.
- Use the correct adapter for your phone when using the battery pack charger abroad.
- Only use the approved battery charger. Otherwise, you may cause serious damage to your phone.

Battery Information and Care

- Please dispose of your battery properly or take it to your local wireless carrier for recycling.
- The battery doesn't need to be empty before recharging.

- Use only LG-approved chargers specific to your phone model since they are designed to maximize battery life.
- Do not disassemble or short-circuit the battery.
- Keep the battery's metal contacts clean.
- Replace the battery when it no longer provides acceptable performance. The battery can be recharged several hundred times before replacement.
- Recharge the battery after long periods of non-use to maximize battery life.
- Battery life will vary due to usage patterns and environmental conditions.
- Use of extended backlighting, Browser, and data connectivity kits affect battery life and talk/standby times.
- The self-protection function of the battery cuts the power of the phone when its operation is in an abnormal state. In this case, remove the battery from the phone, reinstall it, and turn the phone on.
- Unplug the power cord prior to cleaning your phone, and clean the power plug pin when it's dirty.
- When using the power plug, ensure that it's firmly connected. If not, it may cause excessive heat or fire.
- If you put your phone in a pocket or bag without covering the receptacle of the phone (power plug pin), metallic articles (such as a coin, paperclip or pen) may short-circuit the phone. Always cover the receptacle when not in use.
- Don't short-circuit the battery. Metallic articles such as a coin, paperclip or pen in your pocket or bag may short-circuit the + and – terminals of the battery (metal strips on the battery) upon moving. Short-circuit of the terminal may damage the battery and cause an explosion.
- Do not disassemble or crush the battery. It may cause a fire.

General Notice

Explosion, Shock, and Fire Hazards

- Do not put your phone in a place subject to excessive dust and keep the minimum required distance between the power cord and heat sources.
- Using a damaged battery or placing a battery in your mouth may cause serious injury.
- Do not place items containing magnetic components such as a credit card, phone card, bank book, or subway ticket near your phone. The

Safety

magnetism of the phone may damage the data stored in the magnetic strip.

- Talking on your phone for a long period of time may reduce call quality due to heat generated during use.
- When the phone is not used for a long period time, store it in a safe place with the power cord unplugged.
- Using the phone in proximity to receiving equipment (i.e., TV or radio) may cause interference to the phone.
- Do not use the phone if the antenna is damaged. If a damaged antenna contacts skin, it may cause a slight burn. Please contact an LG Authorized Service Center to replace the damaged antenna.
- Do not immerse your phone in water. If this happens, turn it off immediately and remove the battery. If the phone does not work, take it to an LG Authorized Service Center.
- Do not paint your phone.
- The data saved in your phone might be deleted due to careless use, repair of the phone, or upgrade of the software. Please backup your

important phone numbers. (Ring tones, text messages, voice messages, pictures, and videos could also be deleted.) The manufacturer is not liable for damage due to the loss of data.

- When you use the phone in public places, set the ringtone to vibration so you don't disturb others.
- Do not turn your phone on or off when putting it to your ear.
- Use accessories, such as earphones and headsets, with caution. Ensure that cables are tucked away safely and do not touch the antenna unnecessarily.

If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is particularly imperative when attempting to cross the street.

Avoid damage to your hearing

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

FDA Consumer Update



The U.S. Food and Drug Administration's Center for Devices and Radiological Health Consumer Update on Mobile Phones:

1. Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of Radio Frequency (RF) energy in the microwave range while being used. They also emit very low levels of RF when in standby mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

2. What is the FDA's role concerning the safety of wireless phones?

Under the law, the FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit Radio Frequency (RF) energy at a level that is hazardous to the user. In such a case, the FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace, or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, the FDA has urged the wireless phone industry to take a number of steps, including the following:

- Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and

- Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health.

The FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Occupational Safety and Health Administration
- National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

The FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. The FCC relies on the FDA and other health agencies for safety

questions about wireless phones.

The FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are thus not the subject of the safety questions discussed in this document.

3. What kinds of phones are the subject of this update?

The term “wireless phone” refers here to handheld wireless phones with built-in antennas, often called “cell”, “mobile”, or “PCS” phones. These types of wireless phones can expose the user to measurable Radio Frequency (RF) energy because of the short distance between the phone and the user’s head.

These RF exposures are limited by FCC safety guidelines that were developed with the advice of the FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person’s RF exposure decreases rapidly

with increasing distance from the source. The so-called “cordless phones,” which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures far below the FCC safety limits.

4. What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of Radio Frequency (RF) energy exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop cancer in the absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the

conditions under which people use wireless phones, so we do not know with certainty what the results of such studies mean for human health. Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phone RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

5. What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one

exists. Epidemiological studies can provide data that is directly applicable to human populations, but ten or more years follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop — if they do — may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

6. What is the FDA doing to find out more about the possible health effects of wireless phone RF?

The FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to Radio Frequency (RF) energy.

The FDA has been a leading participant in the World Health Organization International Electro Magnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the

development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The project has also helped develop a series of public information documents on EMF issues.

The FDA and the Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research And Development Agreement (CRADA) to do research on wireless phone safety. The FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts with independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

7. How can I find out how much Radio Frequency energy exposure I can get by using my wireless phone?

All phones sold in the United States must comply with Federal Communications Commission (FCC) guidelines that limit Radio Frequency (RF) energy exposures. The FCC established these guidelines in consultation with the FDA and the other federal health and safety agencies. The FCC limit for RF exposure from wireless phones is set at a Specific Absorption Rate (SAR) of 1.6 watts per kilogram (1.6 W/kg). The FCC limit is consistent with the safety standards developed by the Institute of Electrical and Electronic Engineering (IEEE) and the National Council on Radiation Protection and Measurement. The exposure limit takes into consideration the body's ability to remove heat from the tissues that absorb energy from the wireless phone and is set well below levels known to have effects. Manufacturers of wireless phones must report the RF exposure level for each model of phone to the FCC. The FCC website (<http://www.fcc.gov/oet/rfsafety>) gives directions for locating the FCC identification number on your phone so you can find your phone's RF exposure level in the online listing.

8. What has the FDA done to measure the Radio Frequency energy coming from wireless phones?

The Institute of Electrical and Electronic Engineers (IEEE) is developing a technical standard for measuring the Radio Frequency (RF) energy exposure from wireless phones and other wireless handsets with the participation and leadership of FDA scientists and engineers. The standard, "Recommended Practice for Determining the Spatial-Peak Specific Absorption Rate (SAR) in the Human Body Due to Wireless Communications Devices: Experimental Techniques", sets forth the first consistent test methodology for measuring the rate at which RF is deposited in the heads of wireless phone users. The test method uses a tissue-simulating model of the human head. Standardized SAR test methodology is expected to greatly improve the consistency of measurements made at different laboratories on the same phone. SAR is the measurement of the amount of energy absorbed in tissue, either by the whole body or a small part of the body. It is measured in watts/kg (or milliwatts/g) of matter. This measurement is used to determine whether a wireless phone complies with safety guidelines.

9. What steps can I take to reduce my exposure to Radio Frequency energy from my wireless phone?

If there is a risk from these products — and at this point we do not know that there is — it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to Radio Frequency (RF) energy. Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure. If you must conduct extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna. Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

10. What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to Radio Frequency (RF) energy, the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

11. What about wireless phone interference with medical equipment?

Radio Frequency (RF) energy from wireless phones can interact with some electronic devices. For this reason, the FDA helped develop a detailed test method to measure Electro Magnetic Interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical Instrumentation (AAMI). The final draft, a joint effort by the FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI.

The FDA has tested hearing aids for interference from handheld wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a “compatible” phone and a “compatible” hearing aid

at the same time. This standard was approved by the IEEE in 2000.

The FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, the FDA will conduct testing to assess the interference and work to resolve the problem.

12. Where can I find additional information?

For additional information, please refer to the following resources:

FDA web page on wireless phones
(<http://www.fda.gov/cellphones/>)

Federal Communications Commission (FCC) RF Safety Program
(<http://www.fcc.gov/oet/rfsafety>)

International Commission on Non-ionizing Radiation Protection
(<http://www.icnirp.de>)

World Health Organization (WHO) International EMF Project
(<http://www.who.int/emf>)

National Radiological Protection Board (UK)
(<http://www.hpa.org.uk/radiation/>)

10 Driver Safety Tips

Your wireless phone gives you the powerful ability to communicate by voice almost anywhere, anytime. An important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When operating a car, driving is your first responsibility. When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

1. Get to know your wireless phone and its features such as speed dial and redial. Carefully read your instruction manual and learn to take advantage of valuable features most phones offer, including automatic redial and memory. Also, work to memorize the phone keypad so you can use the speed dial function without taking your attention off the road.
2. When available, use a hands-free device. A number of hands-free wireless phone accessories are readily available today. Whether you choose an installed mounted device for your wireless phone or a speakerphone accessory, take advantage of these devices if available to you.
3. Make sure you place your wireless phone within easy reach and where you can reach it without removing your eyes from the road. If you get an incoming call at an inconvenient time, if possible, let your voicemail answer it for you.
4. Suspend conversations during hazardous driving conditions or situations. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, and ice can be hazardous, but so is heavy traffic. As a driver, your first responsibility is to pay attention to the road.
5. Don't take notes or look up phone numbers while driving. If you are reading an address book or business card, or writing a "to-do" list while driving a car, you are not watching where you are going. It is common sense. Do not get caught in a dangerous situation because you are reading or writing and not paying attention to the road or nearby vehicles.

6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan your calls before you begin your trip or attempt to coincide your calls with times you may be stopped at a stop sign, red light, or otherwise stationary. But if you need to dial while driving, follow this simple tip -- dial only a few numbers, check the road and your mirrors, then continue.
 7. Do not engage in stressful or emotional conversations that may be distracting. Stressful or emotional conversations and driving do not mix; they are distracting and even dangerous when you are behind the wheel of a car. Make people you are talking with aware you are driving and if necessary, suspend conversations which have the potential to divert your attention from the road.
 8. Use your wireless phone to call for help. Your wireless phone is one of the greatest tools you can own to protect yourself and your family in dangerous situations -- with your phone at your side, help is only three numbers away. Dial 911 or other local emergency number in the case of fire, traffic accident, road hazard, or medical emergency.
- Remember, it's a free call on your wireless phone!
9. Use your wireless phone to help others in emergencies. Your wireless phone provides you a perfect opportunity to be a "Good Samaritan" in your community. If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.
 10. Call roadside assistance or a special wireless non-emergency assistance number when necessary. Certain situations you encounter while driving may require attention, but are not urgent enough to merit a call for emergency services. But you can still use your wireless phone to lend a hand. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.
- For more information, please call to 888-901-SAFE, or visit our website www.ctia.org.

Consumer Information on SAR

(Specific Absorption Rate)

This model phone meets the government's requirements for exposure to radio waves. Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to Radio Frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although

SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Because the phone is designed to operate at multiple power levels to use only the power required to reach the network, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model.

The highest SAR value for this model phone when tested for use at the ear is 1.24 W/kg and when worn on the body, as described in this user guide, is 0.829 W/kg (body-worn measurements differ among phone models, depending upon available accessories). While there may be differences between SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID BEJLG200C. Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at <http://www.ctia.org>.

* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

FCC Hearing-Aid Compatibility (HAC) Regulations for Wireless Devices

On July 10, 2003, the U.S. Federal Communications Commission (FCC) Report and Order in WT Docket 01-309 modified the exception of wireless phones under the Hearing Aid Compatibility Act of 1988 (HAC Act) to require digital wireless phones be compatible with hearing-aids. The intent of the HAC Act is to ensure reasonable access to telecommunications services for persons with hearing disabilities.

While some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed a rating system for wireless phones, to assist hearing device users find phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label located on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings. **Your LX140 has a M4 rating.**

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. T4 is the better/higher of the two ratings.

Hearing devices may also be rated. Your hearing device manufacturer or hearing health professional may help you find this rating. Higher ratings mean that the hearing device is relatively immune to interference noise. The hearing aid and wireless phone rating values are then added together. A sum of 5 is considered acceptable for normal use. A sum of 6 is considered for best use.



In the above example, if a hearing aid meets the M2 level rating and the wireless phone meets the M3 level rating, the sum of the two values equal M5.

This is synonymous for T ratings. This should provide the hearing aid user with “normal usage” while using their hearing aid with the particular wireless phone. “Normal usage” in this context is defined as a signal quality that is acceptable for normal operation.

The M mark is intended to be synonymous with the U mark. The T mark is intended to be synonymous with the UT mark. The M and T marks are recommended by the Alliance for Telecommunications Industries Solutions (ATIS). The U and UT marks are referenced in Section 20.19 of the FCC Rules. The HAC rating and measurement procedure are described in the American National Standards Institute (ANSI) C63.19 standard.

For information about hearing aids and digital wireless phones

FCC Hearing Aid Compatibility and Volume Control

<http://www.fcc.gov/cgb/dro/hearing.html>

Gallaudet University, RERC

<http://tap.Gallaudet.edu/DigWireless.KS/DigWireless.htm>

Hearing Loss Association of America [HLAA]

<http://www.hearingloss.org/learn/cellphonetech.asp>

The Hearing Aid Compatibility FCC Order

http://hraunfoss.fcc.gov/edocs_public/attachmatch/FCC-03-168A1.pdf

Accessories

To purchase accessories for your new phone such as a hands-free headset, extra battery charger, or replacement battery, please visit www.virginmobileusa.com.



Battery Charger

The battery charger allows you to charge your phone.



Battery

Standard battery is available.



Hands-free Headset

The headset connects to your phone allowing hands-free operation. It includes earpiece, microphone.

Warranty Information

1. WHAT THIS WARRANTY COVERS:

LG offers you a limited warranty that the enclosed subscriber unit and its enclosed accessories will be free from defects in material and workmanship, according to the following terms and conditions:

- (1) The limited warranty for the product extends for TWELVE (12) MONTHS beginning on the date of purchase of the product with valid proof of purchase, or absent valid proof of purchase, FIFTEEN (15) MONTHS from date of manufacture as determined by the unit's manufacture date code.
- (2) The limited warranty extends only to the original purchaser of the product and is not assignable or transferable to any subsequent purchaser/end user.
- (3) This warranty is good only to the original purchaser of the product during the warranty period as long as it is in the U.S, including Alaska, Hawaii, U.S. Territories and Canada.
- (4) The external housing and cosmetic parts shall be free of defects at the time of shipment and, therefore, shall not be covered under these limited warranty terms.
- (5) Upon request from LG, the consumer must provide information to reasonably prove the date of purchase.
- (6) The customer shall bear the cost of shipping the product to the Customer Service Department of LG. LG shall bear the cost of shipping the product back to the consumer after the completion of service under this limited warranty.

Warranty Information

2. WHAT THIS WARRANTY DOES NOT COVER:

- (1) Defects or damages resulting from use of the product in other than its normal and customary manner.
- (2) Defects or damages from abnormal use, abnormal conditions, improper storage, exposure to moisture or dampness, unauthorized modifications, unauthorized connections, unauthorized repair, misuse, neglect, abuse, accident, alteration, improper installation, or other acts which are not the fault of LG, including damage caused by shipping, blown fuses, spills of food or liquid.
- (3) Breakage or damage to antennas unless caused directly by defects in material or workmanship.
- (4) That the Customer Service Department at LG was not notified by consumer of the alleged defect or malfunction of the product during the applicable limited warranty period.
- (5) Products which have had the serial number removed or made illegible.
- (6) This limited warranty is in lieu of all other warranties, express or implied either in fact or by operations of law, statutory or otherwise, including, but not limited to any implied warranty of marketability or fitness for a particular use.
- (7) Damage resulting from use of non-LG approved accessories.
- (8) All plastic surfaces and all other externally exposed parts that are scratched or damaged due to normal customer use.
- (9) Products operated outside published maximum ratings.
- (10) Products used or obtained in a rental program.
- (11) Consumables (such as fuses).

3. STATE LAW RIGHTS:

No other express warranty is applicable to this product. THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. LGE MOBILECOMM USA INC. SHALL NOT BE LIABLE FOR THE LOSS OF THE USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, DIRECT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY APPLICABLE TO THIS PRODUCT.

Some states do not allow the exclusive limitation of incidental or consequential damages or limitations on how long an implied warranty lasts; so these limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

4. HOW TO GET WARRANTY SERVICE:

To obtain warranty service, please call or fax to the following telephone numbers from anywhere in the continental United States:

Tel. 1-800-793-8896 or Fax. 1-800-448-4026

Or visit <http://us.lgservice.com>. Correspondence may also be mailed to:

LG Electronics Service- Mobile Handsets

P.O. Box 240007, Huntsville, AL 35824

DO NOT RETURN YOUR PRODUCT TO THE ABOVE ADDRESS. Please call or write for the location of the LG authorized service center nearest you and for the procedures for obtaining warranty claims.