

Sony Ericsson

User guide

K330


Thank you for purchasing the Sony Ericsson K330. For additional phone content, go to www.sonyericsson.com/fun. Register now to get free online storage and special offers at www.sonyericsson.com/myphone. For product support, go to www.sonyericsson.com/support.


Prior to use, please see important warranty information and terms for safe and efficient use separately provided.

Instruction symbols

The following instruction symbols appear in this User guide:

> Use the navigation key to scroll and select.

 Press the navigation key up.


 Press the navigation key down.


 Press the navigation key to the left.

 Press the navigation key to the right.

 Note

 Tip

 Warning

 Indicates that a service or function is network- or subscription-dependent. All menus or functions may not be available in your phone. Consult your network operator for more information.

Prepare the phone

To insert the SIM card



- 1 Remove the battery cover.
- 2 Slide the SIM card into its holder with the contacts facing down.

To insert the battery



- 1 Remove the battery cover.
- 2 Insert the battery with the label side up and the connectors facing each other.


! Do not force the battery cover into place. Slide the battery cover carefully onto the phone and close it.

To charge the battery




- 1 The phone battery is partly charged when you buy it. Connect the charger to the phone. It takes approximately 2.5 hours to fully charge the battery.
 - 2 To remove the charger, tilt the plug upwards.
- !** You can use the phone during charging. You can charge the battery for more or less than 2.5 hours. Interrupted charging will not damage the battery.

To turn on the phone

- 1 Press and hold down .
- 2 Enter your PIN if requested. To correct mistakes, select **Delete**.
- 3 Select **OK**.
- 4 Select a language.
- 5 Enter the time and date and select **Save**.



To turn off the phone

- Press and hold down .


Standby


After you have turned on the phone and entered your PIN, the name of your operator appears on the screen. This is called standby. You can now make and receive calls.

SIM and PIN

SIM card


The SIM (Subscriber Identity Module) card, which you get from your network operator, contains information about your subscription. Always turn off your phone and detach the charger before you insert or remove the SIM card.












 You can save contacts on the SIM card before removing it from your phone. Contacts may also be saved in the phone memory. See *Contacts* on page 18.

PIN code

You may need a PIN (Personal Identification Number) to activate the services in your phone. Your PIN is supplied by your network operator. Each PIN digit appears as *, unless it starts with emergency number digits, for example, 112 or 911. You can call an emergency number without entering a PIN.

 *If you enter the wrong PIN three times in a row, **PIN blocked. Enter PUK provided by your operator.** appears. To unblock it, you need to enter your PUK (Personal Unblocking Key).*

Menu overview

	Extras	Calendar, Timer, Stopwatch, Calculator, Games & apps, My files, Torch
	Internet	Homepage, Bookmarks, Go to URL, View, Advanced
	FM Radio	
	Camera	Take pic., Record video, Camera pics, Videos, Slide show, Settings
	Messaging	Write new, Inbox, Call voicemail, Drafts, Sent messages, Saved msgs, Templates, Delete messages, Settings, Memory status
	Alarms	
	Calls	Call list, Time and cost, Call settings
	Contacts	View contacts, Find contact, Add contact, My number, Voicemail, Delete contacts, Speed dial, Copy contacts, Send contacts, Settings
	Settings	Sound & alerts, Wallpaper, Theme, Time and date, Language, Bluetooth, Select network, Internet settings, Advanced, Phone status

Some menus and icons in this document may vary depending on operator, network or subscription.

Phone overview




Network coverage





The network bars show the strength of the GSM network in your area. Try moving to another location if you have trouble calling and network coverage is poor. **No network** means you are not in range of a network.

 = Good network coverage

 = Average network coverage

Battery status













 = The phone battery is fully charged

 = The phone battery is empty

Screen icons






These icons may appear on the screen.

Icon Description





- | | |
|--|--|
|  | Battery icon. A completely green icon means the battery is fully charged |
|  | You have missed a call |
|  | Divert calls is activated |
|  | The phone is set to silent |
|  | The keypad is locked |
|  | You have received a text message |
|  | You have received a picture message |
|  | An alarm is activated |
|  | Ongoing call |
|  | The loudspeaker is on |
|  | The FM radio is playing |
|  | The Bluetooth function is activated |

Shortcuts

From standby you can use the navigation keys to go directly to a function:

- Press  to write a text or picture message.
- Press  to go to the camera.
- Press  to play the FM radio.
- Press  to go to your contacts.
- Press , then the left soft key to activate torch.

To navigate the menus

- 1 From standby select **Menu**.
- 2 Press , , ,  and select a menu.


To go back one step in the menu

- Select **Back**.

To return to standby

- Press .

To lock the keypad

- Press  and select **Lock keys**.

To unlock the keypad

- Press  and select **Unlock**.

To set the phone to silent

- Press and hold down .

To call your voicemail service


- Press and hold down .




Calling

You must turn on the phone and be within range of a network.


To make a call

- 1 From standby enter the area code and phone number.
- 2 Press .

To end a call

- Press .

To answer a call

- Press .



To reject a call


- Press .

To turn off the ringtone when receiving a call

- Select **Silent** to turn off the ringtone without answering the call.

To turn on the loudspeaker



- Select **Turn on speaker**.

 *Do not hold the phone to your ear when using the loudspeaker. This could damage your hearing.*


To change the ear speaker volume during a call

- Press  or .

To make international calls

- 1 From standby press and hold down  until a + sign appears on the screen.
- 2 Enter the country code, area code (without the first zero) and phone number.
- 3 Press .



To view a missed call

- When **Missed call** is displayed, select **Details**. To call back scroll to the number and press .


Call list

You can view information about recent calls.

To call a number from the call list

- 1 From standby press .
- 2 Scroll to the name or number and press .


To delete a number from the call list

- 1 From standby press .
- 2 Scroll to the name or number and select **Options > Delete > Yes**.


- ! *Calls to the international emergency number 112 can still be made, even when the keypad is locked.*

Camera

You can take pictures and record video clips to view, save and send. Pictures taken with the camera are saved in **Menu > Camera > Camera pics**. The format is JPEG.

 *Pictures downloaded using picture messages, Internet or Bluetooth are saved in **Extras > My files > My pictures**.*

To start the camera and take a picture


- 1 From standby press . You can see the subject on the phone screen.
- 2 Select **Take pic.** to take the picture.
- 3 Select **Save** or **Delete**.

To delete a picture

- 1 From standby select **Menu > Camera > Camera pics**.
- 2 Scroll to a picture and select **View**.
- 3 Select **Options > Delete > Yes**.

To send a camera picture as picture message

- 1 From standby select **Menu > Camera > Camera pics**.
- 2 Scroll to a picture and select **View**.
- 3 Select **Options > Send message > Options > Send message > To:**.
- 4 Select **Enter phone no.** or **Email address**.
- 5 Select **OK > Options > Send message**.


 *See **To send an item using Bluetooth** on page 31.*

To record a video clip

- 1 From standby select **Menu** > **Camera** > **Record video**.
- 2 Select **Start** to start recording.

To stop recording

- Press **Stop** to automatically save the video clip.


 *The maximum recording time for one clip is 2 minutes.*

To view video clips

- 1 From standby press **Menu** > **Extras** > **My files** > **Videos**.
- 2 Select a video clip to **Play**.

To send a video clip as picture message


- 1 From standby press **Menu** > **Extras** > **My files** > **Videos**.
- 2 Scroll to a video clip.
- 3 Select **Options** > **Send message** > **Options** > **Send message** > **To:**.
- 4 Select **Enter phone no.** or **Email address**.
- 5 Select **OK** > **Options** > **Send message**.

 *The video clip can also be transferred via Bluetooth.*


Messaging

Text messages (SMS)

You must have a service centre number, which is supplied by your service provider and saved on the SIM card. You may have to enter the number yourself. See *Troubleshooting* on page 36.

 See *Entering text* on page 23.

To write and send a text message

- 1 From standby press .
- 2 Select **Text message**. Write the message and select **Options** > **Send message**.
- 3 Select an option.
- 4 Select **Send**.

To view a received text message

- 1 **new message Read now?** appears. Select **View**.
- 2 Select the unread message.

To view messages saved in the inbox

- Select **Menu** > **Messaging** > **Inbox**.


To get delivery status of a sent message

- 1 From standby select **Menu** > **Messaging** > **Settings** > **Delivery report**.
- 2 Select **On**. You will be notified when a message has been successfully delivered.

Picture messages (MMS)

Picture messages can contain text, sound and images. They are sent using MMS to a mobile phone. You need the correct Internet settings in your phone to use this function. See *Internet* on page 31.

To create a picture message

- 1 From standby press .
- 2 Select **Picture messages** > **Options** and select among the options to create the message.


To send a picture message

- 1 When the message is ready, select **Options** > **Send message** > **To:**.
- 2 Select **Enter phone no.** or **Email address**.
- 3 Select **OK** > **Options** > **Send message**.

 *Sending and receiving phones must have subscriptions that support picture messaging.*


Contacts

You can save contacts in the phone memory or on the SIM card. You can copy contacts from the phone memory to the SIM card or from the SIM card to the phone memory.

 See *Entering text* on page 23.

To add a contact

- 1 From standby select **Menu > Contacts > Add contact**.
- 2 Select **Save on SIM** or **Save in phone**.
- 3 Enter the name and select **Options > OK**.
- 4 Scroll to the icon below the name.
- 5 Enter the number and select **OK**.
- 6 Select **Save contact**.



 You can enter the + sign and country code with all phonebook numbers. They can then be used abroad or at home. See *To make international calls* on page 13.

You can choose which contact information is shown as default. If **Phone contacts** is selected as default, your contacts show all the information saved in the phone. If you select **SIM contacts** as default, your contacts show names and numbers saved on the SIM card.


To select contacts view

- 1 From standby select **Menu > Contacts > Settings > View Contacts**.
- 2 Select an option.


To call a contact

- 1 From standby press .
- 2 Select a contact, or enter the first few letters of the contact.
- 3 Press .

To edit a contact

- 1 From standby press .
- 2 Select a contact.
- 3 Select **Options** > **Edit**.
- 4 Edit the information and select **Options** > **Save contact**.

To delete a contact

- 1 From standby press .
- 2 Select a contact.
- 3 Select **Options** > **Delete contact**.

To copy all contacts to the SIM card

- From standby select **Menu** > **Contacts** > **Copy contacts** > **Copy all to SIM**.

To view your own phone number





- From standby select **Menu** > **Contacts** > **My number**.

FM radio



To listen to the FM radio

- 1 Connect the handsfree to the phone.
- 2 From standby press **FM**.

To control the radio

- Press  or  to search for FM radio channels.
- Press  or  to change the volume.

To save an FM radio channel

- When the FM radio is on, press and hold down  – .
- The FM radio channel is saved in **Options > Channels**. You can save up to 20 preset channels.

To exit the FM radio

- Select **Back** or press .

To minimize the FM radio on the screen

- Select **Options > Minimize**.
- Press **FM** to restore the FM radio on the screen.

To turn off the FM radio when minimized

- Press **FM** and select **Back**.

To view FM radio options

- When the FM radio is on, select **Options**.

Calendar

To add an appointment in the Calendar

- 1 From standby select **Menu** > **Extras** > **Calendar**.
- 2 Scroll to a date and select **Options** > **Add a note**.
- 3 Enter your details and select **Options** > **OK**.
- 4 To confirm the date and time, select **OK**.
- 5 Select if you want a reminder signal:
 - **Reminder** – a reminder signal will sound in immediate connection with the note.
 - **Deactivate** – no reminder signal.

To edit or delete a note

- 1 From standby select **Menu** > **Extras** > **Calendar**.
- 2 Scroll to the day for the note and select **Options** > **View today**. If there is more than one note, scroll to the desired note.
- 3 Select **Options**.
- 4 Select to **Delete** or **Edit** the note.

More functions

Alarm

The alarm rings even if the phone is set to silent or turned off.

To set the alarm

- 1 From standby select **Menu > Alarms**.
- 2 Enter the time and select **Save**.
- 3 Select an option.
 - If **Alarm** is selected, select an alarm signal.
 - If **Recurrent alarm** is selected, select what day or days the alarm is going to sound. Scroll to the check boxes and select **Mark** or **Unmark**, then select **Done** and select an alarm signal.



You need to keep a handsfree inserted when you select radio as an alarm signal. The radio will sound through the loudspeaker.

To turn off the alarm

- When the alarm sounds, select **Snooze** or **Stop**.

To set the alarm signal

- 1 From standby select **Menu > Settings > Sound & alerts > Alarm sound**.
- 2 Select an option.









Entering text

There are two methods you can use to enter text: multitap or T9™ text input.













To change text input methods

- When you write the message, press and hold down .

To enter text using multitap

- Press  –  until the desired character appears.
- Press  to add a space.
- Press  to enter full stops and commas.
- Press  to shift between upper case and lower case letters.
- Press  to enter the + sign.
- Press and hold down  –  to enter numbers.

To enter text using T9™ text input

- 1 Press each key only once, even if the desired letter is not the first letter on the key. For example, if you want to write the word “Land”, press , , , .
- 2 If the word shown is the one you want, press  to accept and add a space. To accept a word without adding a space, press . If the word shown is not the one you want, press  or  repeatedly to view alternative words. To accept a word and add a space, press . To enter full stops and commas, press  and then  or  repeatedly.

To add items in a text message

- When you write the message, select **Options** > **Add item**.

To add symbols in a text message

- When you write the message, select **Options** > **Add symbol**.

To delete characters

- Select **Clear**.


To change writing language

- When you write the message, press and hold down .

Emergency calls

Your phone supports international emergency numbers, for example, 112 and 911. These numbers can normally be used to make emergency calls in any country, with or without the SIM card inserted, if a GSM network is within range.

To make an emergency call

- From standby enter 112 (the international emergency number) and press .

To view your local emergency numbers

- From standby select **Menu** > **Calls** > **Call settings** > **Emergency nos.**

Multiple calls

Call waiting

When call waiting is used, you hear a beep if you receive a second call.

To activate call waiting

- From standby select **Menu** > **Calls** > **Call settings** > **Call waiting** > **Activate**.

To answer a second call

- During the call, select **Answer**. Your ongoing call is put on hold.

To reject a second call

- During the call, select **Busy** and continue with the ongoing call.

To make a second call

- 1 During the call, select **Options** > **Hold call** > **Options** > **Call contact**. Your ongoing call is put on hold.
- 2 Select **View contacts**.
- 3 Scroll to the contact and select **Options** > **Call**.

To switch between two calls

- During the call, select **Switch**.

To join two calls

- During the call, select **Options** > **Join calls**.

To end both calls

- Press  twice.


Voicemail

Callers can leave a voicemail message when you can not answer. You can get your voicemail number from your network operator.

To enter your voicemail number

- 1 From standby select **Menu** > **Calls** > **Call settings** > **Set up voicem.** > **OK**.
- 2 Select **Voicemail no.** and enter the voicemail number that you get from your service provider.
- 3 Select **Save**.

To call your voicemail service

- From standby press and hold down .

To check your voicemail number

- From standby select **Menu** > **Contacts** > **Voicemail**.

Ringtones and themes

Themes are used to change the appearance of the screen.

To select a ringtone

- From standby select **Menu** > **Settings** > **Sound & alerts** > **Ringtone** and select a ringtone.

To set the ring volume

- From standby select **Menu** > **Settings** > **Sound & alerts** > **Ring volume** and select an option.

To set the vibrating alert

- From standby select **Menu** > **Settings** > **Sound & alerts** > **Vibration** and select an option.

To select a key sound

- From standby select **Menu** > **Settings** > **Sound & alerts** > **Key sound** and select an option.

To select a theme

- From standby select **Menu** > **Settings** > **Theme** and select a theme.

To use a picture taken with the camera as wallpaper

- 1 From standby select **Menu** > **Camera** > **Camera pics**.
- 2 Scroll to a picture and select **View**.
- 3 Select **Options** > **Set wallpaper**.

Time and date

To set the time

- 1 From standby select **Menu > Settings > Time and date > Time > Set time.**
- 2 Enter the time and select **Save.**

To set the time format

- From standby select **Menu > Settings > Time and date > Time > Time format** and select an option.

To set the date

- 1 From standby select **Menu > Settings > Time and date > Date > Set date.**
- 2 Enter the date and select **Save.**

To set the date format

- From standby select **Menu > Settings > Time and date > Date > Date format** and select an option.

Bluetooth™ wireless technology

Bluetooth™ wireless technology makes wireless connection to other Bluetooth devices, for example, a Bluetooth headset, possible. You can:

- 1 Connect to several devices at the same time.
- 2 Exchange items.

! *The recommended maximum distance between two Bluetooth devices is 10 metres (33 feet), with no solid objects in between.*

To turn on the Bluetooth function

- From standby select **Menu > Settings > Bluetooth > Turn on.**

! *Please check if local laws or regulations restrict the use of Bluetooth wireless technology. If it is not allowed, you must ensure that the Bluetooth function is turned off.*

To show or hide your phone

- From standby select **Menu > Settings > Bluetooth > Visibility > Show phone** or **Hide phone**.



If set to hide, other devices will not be able to identify your phone using Bluetooth wireless technology.

To pair a device with your phone

- 1 From standby select **Menu > Settings > Bluetooth > My devices > New device** to search for available devices.
- 2 Select a device from the list. Enter a passcode, if required.

To pair your phone with a Bluetooth handsfree

- 1 From standby select **Menu > Settings > Bluetooth > Handsfree**.
- 2 Select **Yes** if you are adding a Bluetooth handsfree for the first time or select **Handsfree > My handsfree > New handsfree** if you are pairing with another Bluetooth handsfree. Make sure that your handsfree is ready to be paired.

To receive an item

- 1 From standby select **Menu > Settings > Bluetooth > Visibility > Show phone.**
- 2 When you receive an item follow the instructions that appear.

To send an item using Bluetooth

- 1 From standby select, for example, select **Menu > Camera > Camera pics.**
- 2 Scroll to a picture and select **View.**
- 3 Select **Options > Via Bluetooth.**

Internet

You need the correct Internet settings in your phone. If settings are not in your phone, you can:

- 1 Get them in a text message from the network operator.
- 2 On a computer, go to www.sonyericsson.com/support and request a text message with the settings.

To select an Internet profile

- From standby select **Menu** > **Settings** > **Internet settings** > **Internet profile**. Select a profile.

To start browsing

- From standby select **Menu** > **Internet** and select an option:
 - Homepage** – go to the predefined homepage.
 - Bookmarks** – go directly to a saved Web page.
 - Go to URL** – go to predefined pages or bookmarks, enter a Web address or show previously visited pages.
 - View** – select full screen or text only.
 - Advanced** – select options such as show pictures, allow cookies, clear cookies, clear cache and status.

To stop browsing

- When you browse, press and hold down **Back**.

SIM card lock

The SIM card lock protects your subscription, but not your phone itself, from unauthorized use. If you change SIM cards, the phone still works with the new SIM card. Most SIM cards are locked at the time of purchase. If the SIM card lock is on, you have to enter a PIN (Personal Identity Number) every time you turn on your phone. If you enter your PIN incorrectly three times in a row, the SIM card is blocked. This is indicated by the message **PIN blocked. Enter PUK provided by your operator.** To unblock it, enter your PUK (Personal Unblocking Key). Your PIN and PUK are supplied by your network operator.



*If the message **Wrong code. Attempts remaining:** appears when you edit your PIN, you entered the PIN or PIN2 incorrectly.*

To unblock your SIM card

- 1 When **PIN blocked. Enter PUK provided by your operator.** is displayed, enter your PUK and select **OK**.
- 2 Enter a new PIN and select **OK**.
- 3 Re-enter the new PIN to confirm and select **OK**.

To turn on the SIM card lock

- 1 From standby select **Menu > Settings > Advanced > Security > SIM lock > Protection > On**.
- 2 Enter your PIN and select **OK**.

To edit your PIN

- 1 From standby select **Menu > Settings > Advanced > Security > SIM lock > Change PIN.**
- 2 Enter your PIN and select **OK.**
- 3 Enter a new PIN and select **OK.**
- 4 Re-enter the new PIN to confirm and select **OK.**

To edit your PIN2

- 1 From standby select **Menu > Settings > Advanced > Security > SIM lock > Change PIN2.**
- 2 Enter your PIN2 and select **OK.**
- 3 Enter a new PIN2 and select **OK.**
- 4 Re-enter the new PIN2 to confirm and select **OK.**

Phone lock

The phone lock protects the phone against unauthorized use if it is stolen and the SIM card is exchanged. You can change the phone lock code (which is 0000 by default) to any four-digit personal code.

If the phone lock is set to **Automatic**, you do not need to enter your phone lock code until a different SIM card is inserted in the phone.

To turn on the phone lock

- 1 From standby select **Menu > Settings > Advanced > Security > Phone lock > Protection > On.**
- 2 Enter the phone lock code and select **OK.**

To edit your phone lock code

- 1 From standby select **Menu > Settings > Advanced > Security > Phone lock > Change code.**
- 2 Enter the current code and select **OK.**
- 3 Enter a new code and select **OK.**
- 4 Re-enter the new code to confirm and select **OK.**



If you forget your new code, you have to take your phone to your local Sony Ericsson retailer.

To unlock the phone

- 1 From standby select **Menu > Settings > Advanced > Security > Phone lock > Protection > Off.**
- 2 Enter your phone lock code and select **OK.**

Troubleshooting

Some problems require that you call your service provider, but you can correct most problems yourself. Remove the SIM card before handing your phone in for repair.

Memory capacity and speed

If you have not restarted the phone for a while, you may experience problems with its memory capacity and speed. You can restart the phone to improve its capacity.

- 1 Turn the phone off and remove the battery cover.
- 2 Remove the phone battery and then put it back in place.
- 3 Replace the battery cover and turn the phone on.

Master reset

If you experience problems with your phone such as screen flickering or freezing and navigation problems you should reset the phone.

- From standby select **Menu > Settings > Advanced > Master reset** and select an option.



Reset settings will reset all changes that you have made in your phone to default.

Reset all will delete all user data such as contacts, messages, pictures and sounds in your phone.

I cannot turn on the phone, what should I do?

Try charging the phone until it has finished charging. Attach the charger (make sure the power icon on the charger is facing upwards) and charge the phone for 2.5 hours. The battery icon on the screen may not appear until the phone has charged for 30 minutes.

What is my phone lock code?

A phone lock protects your phone against unauthorized use. If a different SIM card is inserted in the phone, the phone lock code has to be entered. The default phone lock code is **0000**.

What do these error messages mean?

PIN blocked

You have entered the wrong PIN code three times. Your SIM is now locked. Unlock your SIM with your PUK code, which is provided together with your PIN code by your network operator.

- 1 Enter your PUK code and select **OK**.
- 2 Enter a new PIN and select **OK**.
- 3 Re-enter the new PIN to confirm and select **OK**.

Insert SIM card

Your SIM card is not inserted correctly or may be damaged or dirty. Try one or more of the following:

- Remove the SIM card and insert it correctly.
- Clean the connectors on the SIM card and phone with a soft brush, a cloth or a cotton bud.
- Check if the SIM card is damaged.
- Contact your network operator to get a new SIM card.

Declaration of conformity for K330

We, **Sony Ericsson Mobile Communications AB** of
Nya Vattentorget


SE-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type AAA-1002062-BV

and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards EN 301 511:V9.0.2, EN 300 328:V1.7.1, EN 301 489-7:V1.3.1, EN 301 489-17:V1.2.1 and EN 60950-1:2006, following the provisions of, Radio Equipment and Telecommunication Terminal Equipment Directive 1999/5/EC.

Lund, May 2008



Shoji Nemoto, Head of Product Business Group GSM/UMTS

We fulfill the requirements of the R&TTE
Directive (1999/5/EC).

CE 0682

Sony Ericsson K330

GSM 900/1800

This User guide is published by Sony Ericsson Mobile Communications AB or its local affiliated company, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide.

All rights reserved.

© Sony Ericsson Mobile Communications AB, 2008

Please note: Some of the services in this User guide are not supported by all networks. This also applies to the GSM International Emergency Number 112. Please contact your network operator or service provider if you are in doubt whether you can use a particular service or not. Please read the Important information before you use your mobile phone.

All illustrations are for illustration only and may not accurately depict the actual phone.

Your mobile phone has the capability to download, store and forward additional content, e.g. ringtones. The use of such content may be restricted or prohibited by rights of third parties, including but not limited to restriction under applicable copyright laws. You, and not Sony Ericsson, are entirely responsible for additional content that you download to or forward from your mobile phone. Prior to your use of any additional content, please verify that your intended use is properly licensed or is otherwise authorized. Sony Ericsson does not guarantee the accuracy, integrity or quality of any additional content or any other third party content. Under no circumstances will Sony Ericsson be liable in any way for your improper use of additional content or other third party content.

Sony is a trademark or registered trademark of Sony Corporation. Ericsson is a trademark or registered trademark of Telefonaktiebolaget LM Ericsson. The Predictive Text Technology is used under license from Zi Corporation. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Sony Ericsson is under license. The Liquid Identity logo is trademark or registered trademark of Sony Ericsson Mobile Communications AB. Java™ and all Java-based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and other countries.

1. Restrictions: Software is confidential copyrighted information of Sun and title to all copies is retained by Sun and/or its licensors. Customer shall not modify, decompile, disassemble, decrypt, extract, or otherwise reverse engineer Software. Software may not be leased, assigned, or sublicensed, in whole or in part.

2. Export Regulations: Software, including technical data, is subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Customer agrees to comply strictly with all such regulations and acknowledges that it has the responsibility to obtain licenses to export, reexport, or import Software. Software may not be downloaded, or otherwise exported or re-exported (i) into, or to a national or resident of, Cuba, Iraq, Iran, North Korea, Libya, Sudan, Syria (as such listing may be revised from time to time) or any country to which the U.S. has embargoed goods; or (ii) to anyone on the U.S. Treasury Department's list of Specially Designated Nations or the U.S. Commerce Department's Table of Denial Orders. Restricted Rights: Use, duplication or disclosure by the United States government is subject to the restrictions as set forth in the Rights in Technical Data and Computer Software Clauses in DFARS 252.227-7013(c) (1) (ii) and FAR 52.227-19(c) (2) as applicable. All other trademarks and copyrights are the property of their respective owners. Any rights not expressly granted herein are reserved.

www.sonyericsson.com

Sony Ericsson

Sony Ericsson Mobile Communications AB
SE-221 88 Lund, Sweden

1213-4403.3

Printed in Country

This is the Internet version of the User guide. © Print only for private use.