lenovo

YOGA TABLET 8 / YOGA TABLET 10

Quick Start Guide v1.0


Read this guide carefully before using your YOGA TABLET. All information labeled with * in this guide refers only to the WLAN + 3G model (Lenovo B6000-H(V) / Lenovo B8000-H).

Technical specifications

	YOGA TABLET 8	YOGA TABLET 10
Model & version	Model: Lenovo B6000-F; 60043; Z0AF Version: WLAN	Model: Lenovo B8000-F; 60046; Z0AL Version: WLAN
	*Model: Lenovo B6000-H; 60044; Z0AG *Version: WLAN + 3G (Data only)	*Model: Lenovo B8000-H 60047; Z0AJ *Version: WLAN + 3G (Data only)
	*Model: Lenovo B6000-HV; 60045; Z0AH *Version: WLAN + 3G (Voice)	
System	Android 4.2	
[©] Weight	Approx. 401 g *404 g	Approx. 605 g *610 g
CPU	MTK MT8125 Quad Core 1.2 GHz *MTK MT8389 Quad Core 1.2 GHz	
Camera	5 MP AF (back) + 1.6 MP HD (front)	
Battery	6000 mAh	9000 mAh
Display	Size: 8 inches Resolution: 1280 × 800	Size: 10.1 inches Resolution: 1280 × 800
Wireless communication	[©] Bluetooth 4.0 WLAN 802.11 b/g/n GPS *WCDMA, GSM	

Actual product may differ.
Launch with Android 4.2 which only supports BT 4.0 PXP profile.

First glance





Front camera

2 Micro USB

3 On/Off button

4 Speakers

- Microphone
- 6 Volume key


- Earphone jack
- Bracket

Back camera

- microSD card slot
- *Micro SIM card slot
- The WLAN model (Lenovo B6000-F / Lenovo B8000-F) does not have a Micro SIM card slot.
 - (1) Actual product may differ and this dimension only refers to YOGA TABLET 8.
 - 2 Actual product may differ and this dimension only refers to YOGA TABLET 10.

Installing the *Micro SIM card & microSD card

You can use cellular services with the WLAN + 3G model (Lenovo B6000-H(V) / Lenovo B8000-H) by inserting the Micro SIM card provided by your carrier. Install the Micro SIM card and the microSD card as shown.



Only Micro SIM card works with your YOGA TABLET.

!!! DO not insert or remove the Micro SIM card while your YOGA TABLET is turned on. Doing so can permanently damage your Micro SIM card or YOGA TABLET.

Charging and turning on/off your YOGA TABLET

Before using your YOGA TABLET, you might need to charge the battery. Charge the battery as shown.



Connect your YOGA TABLET to a power outlet using the included cable and USB power adapter.

Low battery



Fully charged



Charging

Turn on/off



Turn on: Press and hold the On/Off button until the Lenovo logo is displayed.

Turn off: Press and hold the On/Off button for a few seconds, then tap Power off.

Learn more

For more information about your YOGA TABLET functions, please refer to the "Feature Guide" app in your YOGA TABLET.

For other useful manuals, please access "User Guide" from the Browser favorites in your YOGA TABLET.

For "Regulatory Notices", please go to http://support.lenovo.com/.

Getting support

For support on network service and billing, please contact your wireless network operator. For instructions on how to use your YOGA TABLET, go to http://support.lenovo.com/.

European Union conformity



Radio and Telecommunications Terminal Equipment Directive

This product is in compliance with the essential requirements and other relevant provisions of the Radio and Telecommunications Terminal Equipment Directive, 1999/5/EC.

Legal notices

Lenovo and the Lenovo logo are trademarks of Lenovo in the United States, other countries, or both.

Other company, product, or service names may be trademarks or service marks of others.

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

First Edition (September 2013)

© Copyright Lenovo 2013.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Reduce | Reuse | Recycle





SSC9A463BX Printed in China