

Navigate with ease

Your phone has onscreen navigation buttons at the bottom of the screen which rotate when you change the orientation.

Three of the buttons are standard navigation buttons:

- Tap to go to the Home screen.
- Tap to return to the previous screen.
- Tap to show recently used apps.

The fourth button is optional, and can be set to hide the navigation bar, put your phone into Sleep mode, show the notification list, or show the Quick Settings.

Swipe up from any of the navigation buttons to access Google Search.

Configure the onscreen navigation buttons

- With two fingers, swipe down from the top of the screen to open the Quick Settings.
- Tap **Personalize > Change navigation buttons**.
- Select the fourth navigation button.
- To have only three navigation buttons, make sure none of the fourth button options are selected.
- Rearrange the navigation buttons by dragging next to the button names.
- Tap **Done** to save and apply your customization.

Keep in contact

Check your contact list

Easily communicate with people that matter to you. The People app lists all contacts you've stored on your phone and from online accounts you're logged in to.

- From the Home screen, tap and then find and tap **People**.

- On your contacts list, you can:


- View and edit your profile.
- Create, edit, find, or send contacts.

- Tap a contact photo to find ways to quickly connect with the contact.

- See a notification icon when a contact has sent you new messages.

Add a new contact

- On the People tab, tap **+**.
- Tap the **Name** field, and then enter the contact name.
- Select the Contact type, which indicates the account the contact will sync with.
- Enter the contact information in the fields provided.
- Tap **Save**.



Capture great moments

In the Camera app, tap to choose from the available capture modes.



After taking some shots, use Photo Editor to apply basic and advanced edits to your photos. From the Home screen, tap and then find and tap **Photo Editor**.

Sync music and more

Whether you're at your computer or on the move, HTC Sync Manager lets you enjoy the same rich media. It also stores your same contacts, documents, and other data on both your phone and your computer (compatible with Windows® and Mac OS®).

And, you can use HTC Sync Manager to easily transfer iPhone® photos, text messages, contacts, and more to your phone.

Install HTC Sync Manager

- Download the HTC Sync Manager installer from the HTC support site (www.htc.com/hsm/).
- Launch the installer and follow the onscreen instructions.
- Connect your phone to your computer using the supplied USB cable. HTC Sync Manager opens.

Download more apps

Find new apps in Google Play™ Store for your phone. Choose from a wide variety of free and paid apps ranging from productivity apps, entertainment, to games.

- On the Home screen, tap **Play Store**.
- Browse or search for an app.
- When you find the app that you like, tap it and read its description and user reviews.
- To download or purchase the app, tap **Install** (for free apps) or the price button (for paid apps).
- Tap **Accept**.

Keep it kid-friendly

Worried that your kids might wander off to inappropriate websites or mess with your important work files while using your phone? With Kid Mode®, your children have their own space to enjoy:

- Parent-approved games and apps
- Recorded storybook readings
- Age-appropriate features such as an art board, video messaging, and more

Open the Kid Mode app and follow the instructions to set up your account.

Visual Voicemail

Visual Voicemail allows users to view, listen and save all voicemails in any order directly from the phone, without the need of calling the voicemail system.

- From the Home screen, tap and then find and tap **Visual Voicemail**.
- The inbox with all voicemail messages will be displayed.

If this is the first time accessing Visual Voicemail, you may be asked to enter a new PIN code and tap **Next** to activate Visual Voicemail.

- Tap on a voicemail to listen to it.

T-Mobile Name ID

T-Mobile Name ID identifies callers, displaying name, city and state even if the caller is not in your contacts list. It is an optional add-on feature that can be purchased directly from your phone for an additional monthly charge. A one-time 10-day trial is included with the phone.

- From the Home screen, tap and then find and tap **T-Mobile Name ID**.
- Choose an onscreen option.

Wi-Fi Calling

Wi-Fi Calling can improve your coverage and allows you to make phone calls over a Wi-Fi network (when a Wi-Fi network is available).

To use Wi-Fi Calling, please use the SIM card shipped with your device. A different SIM card may not work with the Wi-Fi Calling feature. You must also have a 9-1-1 emergency address registered with your account. Log into your account at <http://www.t-mobile.com/>. Go to your profile and click **Customer Info** and follow the menu options to register your address.

NOTE: Corporate accounts may require administrator assistance for 9-1-1 address registration.

Turn Wi-Fi Calling on or off

- Go to Settings, and then tap **Call**.
- Under Enhanced communications, select or clear the **Wi-Fi Calling** checkbox.
- Press **↶**.

NOTE: When turning Wi-Fi Calling off, it may take some time before the **Wi-Fi Calling** checkbox clears.

Change the connection preference for Wi-Fi Calling

- Go to Settings, and then tap **Call**.
- Under Enhanced Communications tap **Wi-Fi Calling**.
- Tap **Connection Preferences** and select a connection option.

Accessories

Whether you want a charger, protective case, or a Bluetooth speaker, or you just want to browse for fun extras, T-Mobile is the place to shop for all your phone accessories.

Here are a few examples...



Portable Charger



Speaker



Quick Charger

To purchase accessories for your phone, visit T-Mobile.com, call 1.800.204.2449, or visit your nearest T-Mobile store.

Accessory selection subject to change and may vary by location.

ADDITIONAL INFORMATION

Use of some features, content or services may incur separate, additional charges and/or require qualifying service, or access to a Wi-Fi connection.

Wi-Fi Calling: Wi-Fi connection required for Wi-Fi Calling; may decrement plan minutes. Most devices will not transition between Wi-Fi and the wireless network. See your selected service for details.

Messaging/Data: You will be charged for all messages and data sent by or to you through the network, regardless of whether or not data is received. Character length/file size of messages/attachments may be limited. T-Mobile is not liable for content of messages/attachments or for any failures, delays or errors in any T-Mobile generated alerts or notifications. Your data session, plan or service may be **slowed, suspended, terminated, or restricted** for misuse, abnormal use, interference with our network or ability to provide quality service to other users, or significant roaming.

Downloads/Applications: T-Mobile is not responsible for any third party content or Web site you may be able to access using your phone. Additional charges may apply; not all downloads available on all phones. You obtain no rights in downloads; duration of use may be limited and downloads may be stored solely for use with your phone. T-Mobile is not responsible for any download lost due to your error. T-Mobile is not responsible for Apps, including download, installation, use, transmission failure, interruption or delay, third party advertisements you may encounter while using an App, alterations any App may make to the functionality of your device, **including any changes that may affect your T-Mobile plan, service, or billing, or any content or website you may be able to access through an App.**

Hearing Aid Compatibility: This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

Coverage: Not available in some areas. Devices, screen, and accessory images are simulated. See brochures and **Terms and Conditions (including arbitration provision)** at T-Mobile.com, for rate plan information, charges for features and services, coverage maps, and restrictions and details, including important limitations on availability and reliability of 9-1-1 emergency service when using Wi-Fi calling, microSD is a trademark of SD-3C, LLC. Google Play is a trademark of Google, Inc. All other trademarks are the property of their respective owners. T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. © 2015 HTC Corporation. HTC, the HTC logo, HTC Desire, HTC BlinkFeed, and HTC Sense are trademarks or registered trademarks in the U.S. and/or other countries of HTC Corporation and its affiliates.

CEC Appliance Efficiency Compliance



The BC logo (shown at the left) indicates that this product complies with the California Energy Commission (CEC) energy efficiency standards for battery charger systems set forth at California Code of Regulations Title 20, Sections 1601 through 1608.

T-Mobile

Welcome

Start Guide



htc Desire® 626s



Before you do anything else, please read this

Safety tips

Consider device compatibility

If you have a pacemaker or hearing aid, check with your doctor to make sure it is safe for you to use a cell phone. In some cases, cellular radio frequencies can disrupt the performance of other electronic equipment. If you have questions about the interaction between your phone and any other piece of electronic equipment, ask the equipment manufacturer.

Drive safely

When you are driving, use your phone in a safe and sensible manner. Be aware of laws prohibiting or restricting the use of a cell phone while driving in your area. If allowed, here are a few tips:

- Assess road conditions before answering your phone. Your safety is more important than any call.
- Prepare your hands-free headset, if you have one, or turn on your speakerphone, before you start moving.
- Keep your phone close. If it rings and you discover it's in the back seat, do NOT crawl over the seat to answer it while driving.

Emergency dialing

Although all phones are equipped with 9-1-1 emergency calling, this phone may or may not permit its location to be approximated during a 9-1-1 call.*

* Availability of this feature depends on upgrades to the (a) wireless network and (b) 9-1-1 calling system that are required to be installed by the local 9-1-1 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength, and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped, or refused. The phone's approximate location is transmitted to the local 9-1-1 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions and Privacy Policy for additional service restrictions and details.

Information about safeguarding handsets

T-Mobile encourages customers to take appropriate measures to secure their handsets and invites them to take advantages of the features available on this handset to help secure it from theft and/or other unauthorized access and use. This handset has a locking function (e.g., user-defined codes or patterns) that can serve as a first line of defense against unauthorized use or access to stored information. Preloaded security applications that allow customers to track or locate misplaced devices can be found on several T-Mobile devices. Additional security options are also available to T-Mobile customers on a subscription basis; review handset protection options at www.t-mobile.com/mobilesecurity. Lost or stolen devices should be immediately reported to T-Mobile so that proper measures can be taken to protect accounts. For additional information visit: <http://www.t-mobile.com/Company/PrivacyResources.aspx>.

Approved Firmware Versions: This device will only operate with firmware versions that have been approved for use by T-Mobile and the device manufacturer. If unauthorized firmware is placed on the device it will not function.

Get to know your phone



Set up your phone

Insert the nano SIM and microSD cards

IMPORTANT: Use the nano SIM provided in the box only. Don't cut a micro SIM or regular SIM card and insert it into the nano SIM slot. It's thicker than the standard nano SIM card and may get stuck in the slot.

1. With the phone off and facing **down**, open the slot cover with your thumb or finger.
2. Remove the nano SIM tray. To remove it, insert your fingernail in the small groove in the tray and then pull the tray out.
3. Place your nano SIM card into the tray, with the gold contacts facing **up** and cut-off corner facing **out**.
When reinserting the nano SIM tray, make sure it is facing **up** so that the nano SIM card doesn't fall out. Slide the tray all the way into the slot.

4. Insert your microSD™ card into the bottom slot, with the gold contacts facing **up** and towards the slot. Slide the card all the way in until it clicks into place.
5. To close the slot cover, slide the plastic hinge into the side and press the cover until it clicks into place.

Charge the phone

1. Connect the phone to the power adapter using the provided USB cable.
2. Plug the power adapter into an electrical outlet to start charging.

Turn on the phone

- To turn on the phone, press and hold the POWER button.
- When the phone goes to Sleep mode, briefly press the POWER button and then drag the lock icon up to unlock.

Sign in to your phone


When you switch on your new phone for the first time, you'll be asked to set it up.

Walk through the on-device setup to choose your Internet connection, select how you want to set up your new phone, and more.

Be in the know

Get timely and smart updates on your phone. The HTC Sense® Home widget automatically adapts to where you are, and automatically shows apps that you often use at home, work, or outdoors.

1. On the Home screen, tap **Tap to personalize**.
2. Tap **Let's explore**.



3. Tap your current location.

You can resize or reposition the HTC Sense Home widget to fit more apps, shortcuts, and folders. Over time, the phone learns which apps you use often based on where you are and fills the widget with those apps automatically.



Define your style

Make your phone look and sound just the way you want it. Use the Themes app to apply detailed personalization to your phone. Along with ringtones, wallpaper, and sounds, Themes allows you to change the icon color and shape, app theme color, lock screen, and more.

From the Home screen, tap **Tap to personalize** and then find and tap **Themes**.

Apply a set theme


1. In Themes, tap **≡ > Themes**.
2. Tap one of the themes to download it.
3. Tap **Apply**.

Change your home wallpaper

1. In Themes, tap **≡ > Wallpapers**.
2. Tap one of the wallpapers to download it.
3. Tap **Apply**.
4. Choose where you want to apply the wallpaper, such as to the Home screen.

Pick ringtones and sounds

1. In Themes, tap **≡ > Sounds**.
2. Tap one of the sound schemes to download it.
3. Tap **Apply**.
4. Choose where you want to apply the sound scheme, such as to the Ringtone or Notification.



Add a widget panel

Get more space to create shortcuts to apps, frequently used settings, bookmarked webpages, and more.

1. Press and hold an empty space on a widget panel.
2. In the pop-up menu, tap **Manage home screen pages**.
3. To add a new widget panel, swipe left until you see the **+** icon, and then tap it.

Choose launch bar shortcuts

Fill the launch bar with apps you often use for one-touch access.

- To remove an app, press and hold the app and drag it out of the launch bar.



- To add an app, press and hold an app and then drag it to an empty slot on the launch bar.
- To group apps on the launch bar into a folder, just press and hold an app, and then drag it over to another app.



TCS527800.1

