

# IDEOS S7 Slim

User Guide

# Contents

<b>1 Getting started</b> .....	<b>1</b>
<b>1.1 About your Tablet</b> .....	<b>1</b>
<b>1.2 Getting to know your Tablet</b> .....	<b>1</b>
<b>1.3 Installation</b> .....	<b>3</b>
1.3.1 To remove the back cover.....	3
1.3.2 To install or remove the battery.....	3
1.3.3 To install the back cover.....	4
<b>1.4 Turning your Tablet on or off</b> .....	<b>4</b>
1.4.1 To turn your Tablet on.....	4
1.4.2 To turn your Tablet off.....	5
<b>1.5 Charging the battery</b> .....	<b>5</b>
<b>1.6 Working with the keys</b> .....	<b>6</b>
<b>1.7 Using the touchscreen</b> .....	<b>7</b>
<b>1.8 Home screen</b> .....	<b>8</b>
1.8.1 Getting to know the Home screen.....	9
1.8.2 Home screen extensions.....	10
1.8.3 Customizing the Home screen.....	11

<b>1.9</b>	<b>Locking and unlocking the screen</b> .....	<b>13</b>
<b>1.9.1</b>	To lock the screen .....	13
<b>1.9.2</b>	To set screen timeout period .....	13
<b>1.9.3</b>	To unlock the screen .....	13
<b>1.9.4</b>	To set unlock pattern .....	13
<b>1.10</b>	<b>Text input</b> .....	<b>14</b>
<b>1.10.1</b>	Using onscreen keyboard to enter text .....	14
<b>1.10.2</b>	Cutting or copying text .....	15
<b>1.11</b>	<b>Opening and switching applications</b> .....	<b>16</b>
<b>1.12</b>	<b>Opening the <b>Settings</b> list</b> .....	<b>16</b>
<b>1.13</b>	<b>Setting date and time</b> .....	<b>17</b>
<b>1.14</b>	<b>Installing or removing the microSD card</b> .....	<b>17</b>
<b>1.15</b>	<b>Connecting to or disconnecting from a computer using USB</b> .....	<b>18</b>
<b>1.16</b>	<b>Using Hi Suite to Synchronize</b> .....	<b>20</b>
<b>1.17</b>	<b>Connecting your Tablet to a TV</b> .....	<b>21</b>
<b>2</b>	<b>Wireless networks</b> .....	<b>22</b>
<b>2.1</b>	<b>Wi-Fi</b> .....	<b>22</b>
<b>2.1.1</b>	Opening Wi-Fi settings.....	22
<b>2.1.2</b>	Turning Wi-Fi on or off .....	23

2.1.3	Connecting to a Wi-Fi network	23
2.1.4	Turning open network notification on or off	24
2.1.5	Adding a Wi-Fi Network	24
2.1.6	Forgetting a Wi-Fi network	24
<b>2.2</b>	<b>Bluetooth</b>	<b>25</b>
2.2.1	Opening Bluetooth settings	25
2.2.2	Turning Bluetooth on or off	25
2.2.3	Changing the Bluetooth name of your Tablet	25
2.2.4	Connecting to Bluetooth devices	26
2.2.5	Disconnecting from or unpairing a Bluetooth device	26
2.2.6	Configuring the Bluetooth features	27
<b>3</b>	<b>Google Services</b>	<b>28</b>
3.1	Creating a Google Account	28
3.2	Using Market	29
3.2.1	Searching for Applications	29
3.2.2	Installing an Application	29
3.2.3	Uninstalling an Application	29
<b>4</b>	<b>Browser</b>	<b>30</b>
4.1	Browsing webpages	30

4.1.1 To open Browser .....	30
4.1.2 To navigate within a webpage .....	30
4.1.3 To navigate between webpages .....	31
<b>4.2 Working with bookmarks .....</b>	<b>32</b>
4.2.1 To add a webpage to the bookmarks list .....	32
4.2.2 To open the bookmarks list .....	32
4.2.3 To open a bookmark .....	32
4.2.4 To edit a bookmark .....	33
4.2.5 To share a bookmark .....	33
4.2.6 To delete a bookmark .....	33
<b>4.3 Downloading files .....</b>	<b>33</b>
4.3.1 To download and install only trusted applications .....	33
4.3.2 To download a file .....	34
<b>5 Email .....</b>	<b>34</b>
<b>5.1 Opening Email .....</b>	<b>34</b>
<b>5.2 Adding and deleting email accounts .....</b>	<b>34</b>
5.2.1 To add an email account .....	34
5.2.2 To delete an email account .....	35
<b>5.3 Sending and responding to email messages .....</b>	<b>35</b>

5.3.1 To compose and send email messages .....	35
5.3.2 To receive email messages.....	36
5.3.3 To read an email message.....	36
5.3.4 To reply to or forward an email message .....	36
5.3.5 To delete an email message .....	36
<b>6 Contacts .....</b>	<b>37</b>
6.1 Opening Contacts.....	37
6.2 Creating a contact .....	37
6.3 Searching for contacts.....	38
6.4 Editing contacts .....	38
6.4.1 To edit contact details.....	38
6.4.2 To delete a contact.....	38
6.4.3 To set contact group to display.....	38
<b>7 Multimedia applications.....</b>	<b>39</b>
7.1 Sound Recorder .....	39
7.2 Camera and Camcorder.....	39
7.3 Music.....	40
7.4 Video .....	40
7.5 Photo.....	40

7.5.1 Opening Photo .....	40
7.5.2 Viewing a Picture .....	41
7.5.3 Sharing a Picture .....	41
7.5.4 Rotating a Picture .....	41
<b>8 Handy applications .....</b>	<b>41</b>
8.1 Calendar .....	41
8.2 Weather .....	41
8.3 RSS Reader .....	42
8.4 Memo .....	42
8.5 Alarm Clock .....	42
8.6 Calculator .....	42
8.7 Documents .....	42
8.8 File Manager .....	43
8.8.1 Creating a Folder .....	43
8.8.2 Deleting files and folders.....	43
8.8.3 Searching a File .....	43
<b>9 Personal Information and Data Security .....</b>	<b>44</b>
<b>10 Legal Notice .....</b>	<b>45</b>

# 1 Getting started


## 1.1 About your Tablet

Thanks for choosing IDEOS S7 Slim.

The IDEOS S7 Slim (Tablet for short) is an information terminal that provides convenient and high quality picture, audio, video, networking, and information services based on the Android open source operating system and supports classification and dragging of elements on the home screen. With a full touchscreen, and ultra-thin design, the IDEOS S7 Slim is portable, stylish in appearance, and technically appealing in specification, fully satisfying users' needs.


 Figures in this document are for reference only.

## 1.2 Getting to know your Tablet



- 1 Front camera lens
- 2 Ambient light sensor
- 3 HDMI interface
- 4 Micro USB connector

- 5 Speaker
- 6 Microphone
- 7 microSD card slot
- 8 Dock interface
- 9 LCD screen
- 10 **Back** key
- 11 **Menu** key
- 12 **Home** key




- 13 Power interface
- 14 Rear camera lens
- 15 **Power** key
- 16 Headset jack
- 17 Speaker
- 18 **Volume Up/Down** key

## 1.3 Installation


### 1.3.1 To remove the back cover

To remove the back cover, refer to the following figure.




### 1.3.2 To install or remove the battery

To install the battery, refer to the following figure.




To remove the battery, do as shown in the following figure.



### 1.3.3 To install the back cover

To install the back cover, refer to the following figure.




## 1.4 Turning your Tablet on or off

### 1.4.1 To turn your Tablet on

Before you turn the Tablet on, ensure that the battery is correctly installed or the Tablet has been properly connected to the power supply.

To turn the Tablet on, press the **Power** key.




#### **1.4.2 To turn your Tablet off**

1. Press and hold **Power** key to open the **Tablet options** menu.
2. Touch **Shut Down**.
3. Touch **OK** to confirm shutdown.

#### **1.5 Charging the battery**

Before charging the battery, ensure that the battery is properly installed in your Tablet.

To charge the battery, you can connect the Tablet to the power supply through the power adapter, as shown in the following figure.



## 1.6 Working with the keys

You can enjoy a variety of functions and shortcuts by using the physical keys in addition to the soft buttons.

- **Power**

- Press to turn on the Tablet when it is off.
- Press to turn off and lock the screen when the Tablet is on. And press again to turn on the screen.
- Press and hold to open a menu with options for Silent mode, and for powering off the Tablet.

- **Home**

- Press to open the Home screen. If you are viewing the extensions to the Home screen, it returns to the first panel of the Home screen.
- Press and hold to open the most recently used applications screen.

- **Menu**

- Press to open an option menu with items that affect the current screen or application.

- Press and hold to open the keyboard to perform quick search on some screens.
- While you are on the locked screen and the unlock pattern is not set, press to unlock the screen.
- **Back**
  - Press to return to the previous screen.
  - Press to exit from the running application.
  - If the onscreen keyboard is open, press to close the keyboard.
- **Volume Up/Down**
  - When the Tablet is ringing, press to silence the ringer.
  - On the Home screen, press to increase or decrease the ringtone volume, or set the Tablet to be silent instead of ringing.
  - In other applications, press to control the volume of music, spoken directions, and other audio.
  - Press and hold to quickly increase the ringtone volume to maximum or minimum.

## 1.7 Using the touchscreen

Using your finger, you can manipulate target items such as applications and controls. The Tablet supports the following actions.


Action	Description
Touch	Simply touch items on the screen, such as applications and controls. For example, you can type letters and symbols using the onscreen keyboard.
Touch and hold	Touch and hold an item on the screen until an action occurs. For example, you can usually touch and hold the screen to open the context menu of the active item.

Action	Description
Drag	Touch and hold an item, and then move your finger on the screen until you reach the target position. For example, you can drag a shortcut to the trash to delete it.
Flick	Flick your finger vertically or horizontally across the screen. For example, you can flick up and down to manipulate a scroll bar and flick left and right to switch between pictures.

## 1.8 Home screen

The Home screen is the starting point to access all the applications. When you sign in, press the **Home** key to display, the Home screen. You can customize the Home screen with different wallpapers and display the items you want easiest access to.

## 1.8.1 Getting to know the Home screen




Item	Description
1	<b>Category tabs of the Home screen.</b> You can touch them or flick your finger right or left across the main display area to switch between them.
2	<b>Home screen indicator.</b> The two small dots at the lower left and right of the Home screen corresponding to a category tab indicate the screen that you are viewing.
3	<b>Main display area.</b> Main display area displays application shortcuts, widgets and other items that can be opened by touching them.
4	<b>Status bar.</b> The status bar is at the top of the Home screen, it shows the system status and event notification prompts.

Item	Description
5	<b>System status indicators.</b> It shows the system status such as time, Wi-Fi connection status and signal strength, battery status, and other information. You can touch some of them for more details.
6	<b>Event button.</b> You can touch the event button to open the event manager to view and manage the notifications and tasks.
7	<b>Widgets.</b> Widgets such as picture widget, weather widget, and memo widget are applications that you can use directly on the Home screen.
8	<b>Application button.</b> Touch to open the Applications screen and view the applications installed on your Tablet, and you can touch an application shortcut to run it.

 The pictures are provided only for reference. Your Home screen and Applications screen might look a little different. For details, see the actual product.

### 1.8.2 Home screen extensions

Flick your finger across the Home Screen to go to the Home screen extensions. Home screen extensions to the right provide more space for shortcuts, widgets, and other items. The two small dots above the category tab of the screen indicate the screen that you are viewing.



### 1.8.3 Customizing the Home screen

You can add items such as shortcuts, widgets, Emotion widgets and folders to the Home screen if there is enough room. You can also change the wallpaper of the Home screen.

#### To add an item

1. Flick the Home screen to where you want to add the item.
2. Open the **Add to Home screen** menu, either of the following ways:
  - Touch and hold a blank area on the Home screen until the **Add to Home screen** menu is displayed.
  - When you are on the Home screen, press the **Menu** key, and touch **Add** in the menu opened.
3. In the **Add to Home screen** menu, touch the item type to add. You can add the following types of items to the Home screen:
  - **Shortcuts** Add an application shortcut, a webpage bookmark, a favorite contact, a music playlist, and other items.
  - **Widgets** Add any of a variety of miniature widgets such as an analog clock, a calendar and many other items.
  - **Emotion Widgets** Add any of a variety of Emotion widgets such as Emotion Bookmarks, Emotion Calendar and Events.
  - **Folders** Add a folder where you can organize your Home screen items.
  - **Wallpapers** Set the Home screen wallpaper.

For example, you can touch **Folders** > **New folder** to add a folder to the Home screen, and drag items on the screen to your folder.



If there is not enough room on the Home screen, the add action will be ignored and the user informed with a prompt such as **This group has no room**. Move or delete other items to make room, or switch to another pane of the Home screen where there is room to add an item.

### To move an item

1. Touch and hold an item's icon on the Home screen until the icon magnifies.
2. Without lifting your finger, drag the icon to the target position on the screen.



Pause at the bottom of the screen to drag the item onto the corresponding Home screen panel.

3. Release the item by lifting your finger.

### To remove an item

1. Touch and hold an item icon on the Home screen until the item icon magnifies and the trash icon pops up from on right hand side of the screen.
2. Without lifting your finger, drag the item icon to the trash.
3. When both the item and the trash are focused, release the item by lifting your finger.

### To change the wallpaper

You can change the wallpaper by adding a wallpaper, or as follows.

1. On the Home screen, press the **Menu** key and touch **Wallpaper** on the bottom menu.
2. Choose one of the following steps.
  - Touch **Live wallpapers** to select one of the pre-installed wallpapers.
  - Touch **Photo** to select one of your pictures and set it as the wallpaper.
  - Touch **Wallpaper gallery** to select a picture and set it as the wallpaper.

### To rename a folder

1. Open a folder. Then touch and hold the title bar of the folder window until the **Rename folder** dialog appears.
2. Enter a new name, and then touch **OK**.

## 1.9 Locking and unlocking the screen

### 1.9.1 To lock the screen

When the Tablet is on, press the **Power** key to turn off and lock the screen.

When the Tablet remains idle for a time period that you have set, the screen will automatically lock.



To save your battery or prevent accidental taps when not in use, or when you want to wipe smudges off your touchscreen, turn off and lock the screen.

### 1.9.2 To set screen timeout period

To set how long your screen waits before it turns off automatically, press the **Home** key to go to the Home screen then press the **Menu** key, and touch **Settings > Display > Screen timeout**.

### 1.9.3 To unlock the screen

When the screen is off, you can press the **Power** key to turn on it, and then unlock the screen as follow:

- If you have not set up a screen unlock pattern, press the **Menu** key to unlock the screen, or follow the instructions displayed on the screen and flick upwards to unlock the screen.
- If you have set up a screen unlock pattern, the Tablet prompts you to draw the pattern on the screen to unlock it.

### 1.9.4 To set unlock pattern

To set the unlock pattern, press the **Home** key to go to the Home screen then press the **Menu** key, touch **Settings > Location & security > Set up screen lock > Pattern**, and then follow the instructions on the screen.

## 1.10 Text input

You can enter and edit text in text fields and use menu commands to cut, copy, and paste text, within or across applications.

### 1.10.1 Using onscreen keyboard to enter text

Touch a text field where you want to enter text to open the onscreen keyboard. The following tips will help you to enter text more efficiently.

1. Touch and hold the text field to switch the input method if necessary.
2. Touch the keys on the keyboard to start typing. The following section takes the Android keyboard as an example.
  - When you are typing, the characters you have entered appear in a line above the keyboard, and some with suggestions for the word you are typing to the right. Press space or a punctuation mark to enter the suggestion by default, or touch another suggestion to enter it. You can touch and hold the leftmost word to save it to the dictionary.
  - Touch the up arrowhead key (Shift key) once to capitalize the next letter you type. Or touch and hold the up arrowhead key (Shift key) for all caps.
  - When you touch a key, a larger version displays briefly over the keyboard. Keys with alternate characters display an ellipsis (...) below the character.
  - Touch and hold a vowel or the C, N, S, or Y key to open a small window where you can touch an accented vowel or other alternate letter.
  - Touch and hold the Period key ( . ) to open a small window with a set of common symbol keys.
  - Touch the DEL key to erase a character to the left of the cursor. Touch and hold the DEL key to erase all characters to the left of the cursor.
  - Touch the Symbols key (?123) to switch to the numbers and symbols keyboard, and touch the alphabet key (ABC) to switch back.

- On the numbers and symbols keyboard, touch the ALT key to view additional symbols, and touch it again to switch back.
  - Touch and hold almost any of the number and symbol keys to open a window of additional symbols.
3. When you want to edit the text you have entered, touch to move the cursor to the location where you want to add or delete text. The cursor is a vertical bar that indicates where text you type or paste is inserted.
  4. When you have finished typing, touch the button to the right of the text field or the same button on the keyboard or press the Back key to close the keyboard.

### 1.10.2 Cutting or copying text

To quickly cut or copy all the text in a text field:

1. Touch the text field that contains the text to cut or copy to open it.
2. Touch and hold the text field to display the **Edit text** menu.
3. Touch **Cut all** or **Copy all**.

To cut or copy selected text in a text field:

1. Touch the text field that contains the text to cut or copy.
2. Touch to move the cursor to the beginning or end of the text to be selected.
3. Touch and hold the text field to display the **Edit text** menu.
4. Touch **Select text** and touch to move the cursor to the end or beginning of the text to be selected. Or touch **Select all** to select all the text in the text field. The selected text is highlighted.
5. Touch and hold the text field again to display the **Edit text** menu.
6. Touch **Cut** or **Copy**.

After you cut or copy text, the text is stored in a temporary area so that you can paste it into other text field. Before you can paste, you must have cut or copied text at least once. Once

you cut or copy text, you can paste multiple times. To paste the most recent text that you have cut or copied in another text field:

1. Touch the text field where you want to paste the text.
2. Touch to move the cursor to the location where you want to paste the text.
3. Touch and hold the text field to display the **Edit text** menu.
4. Touch **Paste**.

## 1.11 Opening and switching applications

To open an application, touch its shortcut on the Home screen, or on the Applications screen which can be opened by touching the Application button on the Home screen.

To switch to a recently used application, press and hold the **Home** key, and touch the application icon in the small window that opens with shortcuts to applications that you have used recently. Or touch the Event button to open the **Event Manager** and touch to open a recently used application in the **Tasks** list.

## 1.12 Opening the **Settings** list

Open the settings list to view or change the settings of wireless and cellular networks, sound and display, location and security, applications, language and keyboard, date and time, and other items.

- When you are on the Home screen, press the **Menu** key, and touch **Settings** in the menu opened.
- When you are on the home screen, touch the Application button and touch **Settings** to open the scroll list.
- If you recently opened the settings list, you can touch the Event button on the status bar to display **Event Manager**, and touch **Settings** in the **Tasks** scroll list that opens.

## 1.13 Setting date and time

By default, the Tablet automatically uses the network provided date, time zone, and time.




When the time provided by the network is automatically used, you cannot set the date, time, and time zone by yourself.

To manually set date and time:

1. Open the **Settings** list.
2. Touch **Date & time**.
3. Touch **Automatic** to make it unchecked.
4. Touch **Set date**. Then touch the plus button or the minus button to adjust the date, month, and year, or touch the text field of date, month, and year to enter them. Touch **Set** when finished.
5. Touch **Select time zone**, then select the correct time zone from the list. Scroll down the list to view more time zones.
6. Touch **Set time**. Then touch the plus button or minus button to adjust the hour and minute, or touch the text field of hour and minute to enter them. Touch **Set** when finished.

## 1.14 Installing or removing the microSD card

Insert your microSD card into the microSD card slot until it clicks into position as shown in the following figure.




 To remove the microSD card, gently push the card into the slot, then release it. The card will eject from the slot, and can then be removed.


## 1.15 Connecting to or disconnecting from a computer using USB

To connect your Tablet to a computer using USB:

1. Use the USB cable supplied with your Tablet to a USB port on your computer. The Tablet displays a notification indicating that the USB is connected.



 Do not connect the Tablet to a PC to charge the Tablet, as shown in the following figure. Doing so may damage your Tablet and the PC.



2. Touch the Event button to open the **Event Manager** and touch **USB connected** in the **Notifications** list.
3. Touch **Turn on USB storage** in the dialog that opens to confirm that you want to transfer music, pictures, and other files between your Tablet storage or microSD card storage and the computer.

To disconnect your Tablet from the computer safely and avoid losing information, carefully follow your computer operating system's instructions to disconnect USB devices, and do the following:

1. Touch the Event button to open the **Event Manager**.
2. Touch **Turn off USB storage** in the **Notifications** list.
3. Touch **Turn off USB storage** in the dialog opens.



When the Tablet is connected to your PC for the first time, an installation wizard will run automatically. Follow the wizard to install the driver. It takes only a few minutes to finish the installation. After the driver is successfully installed, it does not need to be installed again the next time you connect your Tablet to the PC. If the installation wizard does not run the first time you connect your Tablet to your PC, open **My Computer** and then the CD drive with Huawei logo. Run **Setup.exe** to launch the installation wizard.

## 1.16 Using Hi Suite to Synchronize

Install the Hi Suite stored in your Tablet. Follow the instructions on your computer to complete the installation. You can now synchronize your contacts and calendar appointments between your PC and Tablet. For more details, please refer to the Hi Suite help.



Hi Suite is designed to work on Windows XP SP2, Windows Vista, and Windows 7. It is recommended that you use one of these systems.

## 1.17 Connecting your Tablet to a TV

You can connect your Tablet to a TV to output audio and video from the Tablet to the TV. Playing pictures, videos, and music on your Tablet via a TV brings you a better experience.


You must use a High-Definition Multimedia Interface (HDMI) cable to connect the Tablet to the TV. As the HDMI cable is an optional accessory, it may not be included in the packing box. When you purchase an HDMI cable, check the connector type of the cable.

- The connector that connects the HDMI cable to the HDMI interface of your Tablet is a Type D connector.
- The connector that connects the HDMI cable to the HDMI interface of the TV varies according to the HDMI interface of the TV. Typically, it is a Type A connector.

Your Tablet's HDMI connection supports only  $800 \times 480$  pixels resolution output format. Due to the fact that some TVs may not support  $800 \times 480$  pixels HDMI resolution, you may not be able to view Tablet display on the TV. Please consult your TV manufacture for information on HDMI support.

Connect your Tablet to the TV as follows:

1. Connect the HDMI cable to the HDMI interfaces of the Tablet and the TV.



2. Select the TV's correct program source for the HDMI interface.

## 2 Wireless networks

Your Tablet can connect to a variety of wireless networks and devices, including Wi-Fi data networks, Bluetooth devices such as headsets, and mobile networks for voice and data transmission.



Using a wireless device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

### 2.1 Wi-Fi

Wi-Fi is a wireless networking technology that can provide wireless Internet access over distances of up to 300 feet (100 meters). The capability of your Wi-Fi connection depends on the Wi-Fi router and the surroundings in which it works. To use Wi-Fi on your Tablet, you need to access a wireless access point or "hotspot". You can simply connect to some open access points, but for others, that are hidden or that have security protection such as authentication and encryption, you will be required to configure your Tablet to gain access.

#### 2.1.1 Opening Wi-Fi settings

You can turn Wi-Fi on or off, turn the open network notification on or off, connect to a Wi-Fi network and add Wi-Fi networks in the Wi-Fi settings list. To open the Wi-Fi settings list:

1. Open the **Settings** list.
2. Touch **Wireless & networks**, and then touch **Wi-Fi settings**.



When you are viewing the **Wi-Fi settings** list, you can press the **Menu** key and touch **Advanced** in the menu that opens to see your IP settings or other Wi-Fi details.

### 2.1.2 Turning Wi-Fi on or off

To turn Wi-Fi on or off, you can open **Wi-Fi settings** and touch **Wi-Fi** to make it checked (on) or unchecked (off).



To extend your battery life, turn Wi-Fi off when you are not using it.

### 2.1.3 Connecting to a Wi-Fi network

When you turn Wi-Fi on, the available Wi-Fi networks found within range are listed with the names and security scheme information, and secured networks are indicated with a lock icon. You can view the **Wi-Fi networks** list by opening **Wi-Fi settings**.

To connect to a Wi-Fi network, touch a network you want to connect to in the **Wi-Fi networks** list on the **Wi-Fi settings** screen. If the network is open, you are prompted to confirm that you want to connect to that network by touching **Connect**. If the network is secured, you are prompted to enter a password or other credentials. (Contact your service provider for details.) If your Tablet can't connect to the network after you enter a password, check whether the encryption method, password type, password, and certificate are correct.

When the encryption mode is set to WEP, if the network is in a state of obtaining IP after you enter a password, check whether the password is correct. For a solution, please touch its name in the **Wi-Fi networks** list, touch **Forget**, enter the correct WEP password and try again.



When you are in range and Wi-Fi is on, you will automatically reconnect to available networks that you have connected to previously.

When you are connected to a network, you can touch its name in the **Wi-Fi networks** list for details about the speed, security, address, and related settings.

### 2.1.4 Turning open network notification on or off

When Wi-Fi is on, you can touch **Network notification** to make it checked or unchecked to turn open network notification on or off in the **Wi-Fi settings** list, after which you will receive or stop receiving notifications in the status bar when open networks in range are detected.

### 2.1.5 Adding a Wi-Fi Network

When a Wi-Fi network with security credentials does not broadcast its name (SSID), or it is not in range, you can add and save the network settings and connect to it when it is available. Contact the Wi-Fi network service provider for details about the network's security scheme and to obtain the password or other required security credentials. The name (SSID) and credentials are saved and you are automatically connected to this network if it is in range and Wi-Fi is on.

When Wi-Fi is on, do the following to add a Wi-Fi Network:

1. In the **Wi-Fi settings** list, flick down and touch **Add Wi-Fi network**.
2. Enter the name (SSID) of the network in the **Network SSID** text field. If the network is secured, touch the **Security:** button and then touch to select the security scheme in the menu that opens.
3. Enter any required security credentials.
4. Touch **Save**.

### 2.1.6 Forgetting a Wi-Fi network

To remove a Wi-Fi network that you do not want to connect to automatically or you no longer use when Wi-Fi is on:

1. Touch and hold a Wi-Fi network you have connected to previously in the **Wi-Fi networks** list on the **Wi-Fi settings** screen.
2. Touch **Forget network** in the menu that opens.

## 2.2 Bluetooth

Bluetooth is a short-range wireless communication technology for exchanging information between Bluetooth devices such as headphones and mobile phones over a distance of about 10 meters. The capability of your Bluetooth connection depends on your surroundings and may be reduced by obstacles such as a wall or other electronic devices.

### 2.2.1 Opening Bluetooth settings

You can turn Bluetooth on or off, change the Bluetooth name of your Tablet, connect to a Bluetooth device and scan to view Bluetooth devices in the Bluetooth settings list.

To open Bluetooth settings list:

1. Open the **Settings** list.
2. Touch **Wireless & networks**, and touch **Bluetooth settings**.



When you are viewing the **Bluetooth settings** list, you can touch **Scan for devices** in the menu that opens to scan for Bluetooth devices.

### 2.2.2 Turning Bluetooth on or off

To turn Bluetooth on or off, open the **Bluetooth settings** and touch **Bluetooth** to make it checked (on) or unchecked (off).



To extend your battery life, turn Bluetooth off when you are not using it.

### 2.2.3 Changing the Bluetooth name of your Tablet

The Bluetooth name of your Tablet is visible to other Bluetooth devices when you connect to them. When Bluetooth is on, do the following to change the Bluetooth name of your Tablet:

1. Touch **Device name** in the **Bluetooth settings** list.
2. Enter the new name in the dialog that opens, and then touch **OK**.

## 2.2.4 Connecting to Bluetooth devices

The first time you connect to a Bluetooth device, you must pair the Bluetooth of your Tablet with the Bluetooth device to make sure they connect securely to each other; after this, you can simply connect to a paired device when Bluetooth is on.

### To pair with a Bluetooth device

1. When Bluetooth is on, all the available Bluetooth devices in range are listed in the **Bluetooth devices** list on the **Bluetooth settings** screen.
2. Touch **Discoverable** to make the Bluetooth of your Tablet discoverable.
3. If the device you want to pair with is not in the list, follow the instruction documentation that came with the device to make it discoverable and touch **Scan for devices** to display it.
4. Touch the device entry in the **Bluetooth devices** list to pair them. The devices pair with each other.
5. If you are prompted to enter a passkey (for example 0000), refer to the documentation that came with the device to learn its passkey. If the pairing is successful, your Tablet connects to the device.

### To connect to a paired Bluetooth device

When you switch off Bluetooth devices or a paired Bluetooth device come back into range, you can reconnect to it. To automatically reconnect your Tablet with the paired device, simply turn on the device. To manually reconnect your Tablet with a paired device, touch the device name in the **Bluetooth devices** list.

## 2.2.5 Disconnecting from or unpairing a Bluetooth device

To automatically disconnect your Tablet from a paired device, simply turn off the device.

To manually disconnect your Tablet from a paired device or unpair this device to erase all the pairing information about it, do the following:

1. Touch and hold the device in the **Bluetooth devices** list on the **Bluetooth settings** screen.
2. Touch **Unpair** to confirm that you want to disconnect or unpair.

### **2.2.6** Configuring the Bluetooth features

Some Bluetooth devices have multiple profiles. Profiles can include the ability to transmit conversations, or to play music in stereo. You can select which profiles you want to use with your Tablet to configure the Bluetooth features.

1. Touch and hold the device in the **Bluetooth devices** list on the **Bluetooth settings** screen.
2. Touch **Options...** in the menu that opens.
3. A screen opens with a list of profiles for the device.
4. Touch a profile to make it checked or checked to use it or not.
5. When you are finished, press the **Back** key.

## 3 Google Services

### 3.1 Creating a Google Account

When you first turn on your Tablet, touch a Google service icon, such as **Market**, and you will be prompted to sign in to your Google account.



When creating a Google account, ensure that your Tablet is connected to a network.

If you already have a Google account, touch **Sign in** and enter your username and password.

If you do not have a Google account, you can create one:

1. After reading the setup information, touch **Next**.
2. Touch **Create**.
3. Enter a first name, last name, and user name for your Google account, and then touch **Next**. The tablet will connect to the Google server to check whether the username is available. If the username you entered is already in use, you will be prompted to choose another one or select one from a list.
4. Enter and confirm your Google account password.
5. Select a security question from the drop down menu, and then enter the answer.
6. Touch **Create**.
7. When **Google Terms of Service** screen appears, touch **I agree, Next**.
8. Enter the characters that appear on the screen, and then touch **Next**.



To use another account, go to the **Accounts & sync** settings screen, and touch **Add account** to select which type of accounts you want to add.

## 3.2 Using Market

Android Market provides direct access to applications and games which you can download and install on your Tablet.

### 3.2.1 Searching for Applications

There are a few different ways to find applications on the Market screen, including:

1. Featured applications.
2. List of games.
3. Search function.
4. Your downloads.

### 3.2.2 Installing an Application

1. On the **Market** screen, touch **Apps**.
2. Touch a category, and then touch the item you want to download.
3. To install the item, touch **FREE** (if the item is free) or **Buy**, whichever is displayed.
4. To check the progress of a download, open the notification panel. Most applications are installed within seconds. To stop an item from downloading, touch **Cancel**.
5. After the application has been downloaded and installed on your Tablet, the content download icon appears in the notification bar.



If you want to install a non-Market application, press the **Menu** key and touch **Settings** > **Applications**, and then select the **Unknown sources** to allow installation of the non-Market application.

### 3.2.3 Uninstalling an Application

1. On the Market screen, touch **My apps**.
2. Touch the application you want to uninstall, and then touch **Uninstall**.
3. When prompted, touch **OK** to remove the application from your Tablet.

4. Choose the reason for removing the application, and then touch **OK**.

## 4 Browser

Use **Browser** to view webpages and to search for information on the web.



Your Tablet may not support Flash. If you want to browse Flash on some Web pages, please download Flash Player from **Market**. For detailed information about how to download Flash Player, refer to the section **Market**.

### 4.1 Browsing webpages

#### 4.1.1 To open Browser

Touch **Browser** on the Home screen or on the Applications screen to open the **Browser** and start surfing the web.

##### To enter a webpage address

When you are on a **Browser** screen, touch the address bar to enter the address (URL) of a new webpage. When you are entering the address, the web search makes suggestions of webpages and queries. You can touch a suggestion or continue to enter the address and touch **→** to open a webpage.

##### To refresh a webpage

When you are on a **Browser** screen, Touch  to reload the webpage and view the updated content.

##### To stop loading a webpage

If a webpage is taking a long time to open, or if you change your mind, you can Touch **×** to stop it from loading.

#### 4.1.2 To navigate within a webpage

The following tips help you to navigate within a webpage.

- Flick your finger on the screen to scroll up and down.
- Touch the plus or minus side of the zoom control to zoom in or out.
- To find text on a webpage. Touch  and then touch **Find on page**. Enter the text you are looking for. As you type, the first word with matching characters is highlighted on the screen, and subsequent matches are boxed. Touch the left arrowhead or right arrowhead to jump to and highlight the previous or next matching word.

#### 4.1.3 To navigate between webpages

You can open links on a webpage, navigate back and forth, and review your browsing history, just as in any web browser. You can also take advantage of some shortcuts for working with links and other kinds of information. The following tips help you to navigate among webpages.

- Touch a link to open it. Links that you touch are highlighted until the webpage they refer to opens in the window.
- To go back and forward among the pages you have opened, Touch  or  at the bottom of the webpage.
- As you browse the web, **Browser** keeps track of the pages you visit, to help you find your way back later. You can touch the  at the bottom of the webpage and touch the **History** tab. The pages you have visited are grouped chronologically. Touch a time period to view the pages you have visited. Touch a page in the history tab to reopen it.
- To view your most frequently visited pages, touch  at the bottom of the webpage and touch the **Most visited** tab. The pages you have visited most frequently are listed in order. Touch a page to open it.
- Browser recognizes links, as well as some phone numbers, addresses, and similar information that you may want to act on directly. To follow shortcuts for links, phone numbers, and addresses, touch and hold a link to open a menu with shortcuts for opening, adding to the bookmark, saving, and sending the link via email.

- You can open Multi **Browser** windows at a time and switch between them. To open a new **Browser** window, Touch . In the screen that opens, touch **New window**. New windows open with your home page.
- To switch **Browser** windows, Touch . Your open windows are displayed. Touch a window to open it.
- To close a **Browser** window. Touch . All open windows are displayed in a scrolling list of thumbnails. Touch the close box on the window to close it. Or you can touch  at the bottom of the webpage to close a Browser window.

## 4.2 Working with bookmarks

You can add webpages to the bookmarks list so that you can quickly return to them.

### 4.2.1 To add a webpage to the bookmarks list

1. Open a webpage to add to the bookmarks list.
2. Touch  at the bottom of the webpage.
3. Touch **Add bookmark** at the bottom of the **Bookmarks** screen.
4. Edit the name and the folder if necessary and touch **OK**. The bookmark is added to the top of your bookmarks list.

### 4.2.2 To open the bookmarks list

Touch  on the browser screen.

### 4.2.3 To open a bookmark

In the bookmarks list, touch a bookmark to open it. The bookmark opens in the current window. If you prefer to open it in a new window, touch and hold the bookmark and touch **Open in new window** in the menu that opens.

#### 4.2.4 To edit a bookmark

1. In the bookmarks list, touch and hold the bookmark to edit.
2. Touch **Edit bookmark** in the menu that opens.
3. Edit the name or folder in the dialog that opens and touch **OK**.

#### 4.2.5 To share a bookmark

1. In the bookmarks list, touch and hold the bookmark to share.
2. Touch **Share link** in the menu.
3. Touch the application you want to use to send the bookmark. The application opens with the bookmark address.

#### 4.2.6 To delete a bookmark

1. In the bookmarks list, touch and hold the bookmark to be deleted.
2. Touch **Delete bookmark** in the menu, and touch **OK**.

### 4.3 Downloading files

You can download files, webpages, and even applications from webpages. The files that you download are stored on your Tablet.

#### 4.3.1 To download and install only trusted applications

You can download and install applications from the web or received with an email message. Applications downloaded from the web can be from unknown sources. To protect your Tablet and personal data, you can set your Tablet to download applications only from trusted sources; open the settings list and touch **Applications > Unknown sources > OK** to make it unchecked.

### 4.3.2 To download a file

You can touch and hold an image and touch **Save image** in the menu that opens to download the image file. Or touch and hold a link to a file or to another webpage, and touch **Save link** in the menu that opens to download the linked file.

## 5 Email

### 5.1 Opening Email

Touch **Email** on the Home screen or on the Applications screen to open **Email**.

### 5.2 Adding and deleting email accounts

#### 5.2.1 To add an email account

The first time you open **Email**, you are prompted to set up an email account. Or if you have created an email account, you can touch **Add account** to create another email account. To add your email account, in the **Set up Email** screen:

1. Touch **New account**.
2. Select an account type (**Gmail** or **Other**).
  - If you already have a Gmail account, touch **Gmail** and enter your email address and password. Then touch **Sign in**.
  - If you want to add another type of email account, touch **Other** and enter an email account and password. Select the mailbox type and enter other email account details. For details about your email account, contact your email service provider.
3. Touch the **Back** key to select your email service type and enter other email account details. You can contact your email service provider for the values required for your account.
4. Touch **Done**, and then touch **Sign in** Email starts downloading your email messages and you can send and receive email messages with this new account.

### 5.2.2 To delete an email account

1. Open the **Email** screen.
2. Touch and hold the account to delete.
3. Touch **Delete** in the menu that opens.
4. Touch **OK** in the dialog to confirm your delete action.

## 5.3 Sending and responding to email messages

### 5.3.1 To compose and send email messages

1. Open **Email**, touch the email account you want to use.
2. Touch **New email** at the bottom of the screen.
3. Enter the names or email addresses of the desired recipients in the **To:** field. As you enter, matching addresses are offered from your **Contacts**. You can touch a suggested address or enter a new one. Separate multiple addresses with commas. You can also enter names or email addresses of recipients in the **Cc/Bcc:** field to send a copy of the email to those recipients.
4. Enter a subject for the email message.
5. Enter the text of the email message.
6. Press the **Back** key and touch **Attachment** to attach a file or photo to the email.
7. Touch **Send**.



If you are not ready to send the message, you can touch **Cancel** to abandon the message, or touch **Save as draft** to save it in a drafts folder. Your message is also saved as a draft if you press the **Back** key before sending it.

### 5.3.2 To receive email messages

To receive emails, touch the desired email account and then touch **Check** at the bottom of the screen. You can also touch **Settings > Email check frequency** to set the frequency for automatically checking new emails.

### 5.3.3 To read an email message

To read an email message, you can open the **Email** screen, touch to select an account inbox, then touch the message to read. Alternatively you can touch and hold the message, and then touch **View details** in the menu that opens.

### 5.3.4 To reply to or forward an email message

While reading an email message, you can touch **Reply** or **Reply all** to reply to the message. A Compose Message window opens with the addresses, subject, and a copy of the message you are responding to filled in.

### 5.3.5 To delete an email message

You can delete an email message from its folder by touching **Delete**, and then **OK** when you are reading it. For most kinds of accounts, deleted messages are moved to a trash folder, so you can retrieve them if you deleted them in error.

## 6 Contacts

**Contacts** enables you to save and manage information such as phone numbers, email addresses and chat addresses of your contacts, and provides quick and easy access to communicate with the people you want.

### 6.1 Opening Contacts

You can open your contacts by touching **Contacts** on the Home screen or on the Applications screen. In the contact tab pages, you can touch a contact to open the contact details screen, or touch and hold a contact to open the context menu.

### 6.2 Creating a contact

1. Open the **Contacts** screen.
2. Touch **Create**.
3. Enter the contact's information, referring to the following tips.
  - Enter the contact name, and touch the picture frame to select a picture to display next to the name in the contacts list and in other applications.
  - Touch a category of contact information, such as phone numbers and email addresses, to enter that kind of information about your contact. Flick up and down to view all categories.
  - Touch the plus button to the right of a category to add more than one entry for that category. Touch the minus button to the right of an entry to remove the entry.
  - Touch the label button to the left of the items of contact information such as **Phone** and **Email** to open a menu with preset labels for a phone number. You can touch to select a preset label or touch **Custom** in the menu to create your own label.
4. When you have finished entering details, flick to the bottom of the page and touch **Save** to save the contact details to your Tablet.

## 6.3 Searching for contacts

1. Open the **Contacts** screen.
2. Touch **Search**.
3. Enter the name of the contact you are searching for. As you type, contacts with matching names appear below the search box.
4. Touch a matching contact in the list to open its Details screen.

## 6.4 Editing contacts

### 6.4.1 To edit contact details

To change or add details for your contacts:

1. Open **Contacts**.
2. Touch and hold the contact whose details you want to edit, and touch **Edit contact** in the menu that opens. You can also touch **Edit** while viewing details of the contact.
3. Edit the contact information, using the same controls as when you create a contact.

### 6.4.2 To delete a contact

1. Open **Contacts**.
2. Touch and hold the contact to delete, and touch **Delete contact** in the menu that opens. You can also touch **Delete** while viewing details of the contact.
3. Touch **OK** to confirm that you want to delete the contact.



To delete multiple contacts, touch **Delete** at the bottom of the **Contacts** tab to access the **Delete contact** screen. Select the contacts you want to delete. Touch **Delete** and then **OK** to delete the selected contacts.

### 6.4.3 To set contact group to display

To set the contact group to display:

1. Open **Contacts**.
2. Touch **Display options**.
3. Touch **Only contacts with phones** to make it checked or unchecked to display only contacts with phones or display all contacts.
4. Touch **Done** to confirm that you want to display the contact group.

## 7 Multimedia applications

### 7.1 Sound Recorder

Touch **Sound Recorder** on the Applications screen to open the **Sound Recorder** screen.

- Touch the round button to start to record your message.
- Touch the triangle button to play back the recording.
- Touch the square button to stop recording or playing.
- View the recording or playing duration and the volume of the captured audio signals on the **Sound Recorder** screen.

### 7.2 Camera and Camcorder

Touch **Camera** or **Camcorder** on the Home screen or on the Applications screen to open the camera or camcorder to take pictures or shoot videos.



Be sure to clean the protective lens cover with a microfiber cloth before taking pictures and shooting videos. A lens cover with smudges from fingers can cause blurry pictures with a “halo” effect.

On the Camera screen, press the **Menu** key to do the following: touch **Secondary camera** to switch to the secondary camera; touch **Switch to video** to switch to Camcorder; or touch **Photo** to access the **Photo** screen. On the **Camcorder** screen, press the **Menu** key to perform similar actions.

## 7.3 Music

Touch **Music** on the Home screen or on the Applications screen to open the music player and display the music library that can be organized by **Artist**, **Genre**, **Album**, **Release**, **Songs**, or **Playlist**. You can select what you want to play.



To add a song to a playlist, touch and hold the desired song to access the shortcut menu and select **Add to playlist**.

## 7.4 Video

On the Applications screen, touch **Video** to open the **Video** screen and display the video files. On the **Video** screen, touch a file to play the video.

## 7.5 Photo

**Photo** can automatically search for the pictures stored on your Tablet and microSD card. In addition, **Photo** sorts these pictures in folders. You can use **Photo** to view and edit pictures, set a picture as the wallpaper or a contact image.



On the **Photo** screen, you can share, star, sort, and delete pictures by touching relevant options at the bottom of the screen. After you touch **Share**, **Starring**, or **Delete**, select the pictures you want to process and touch the desired option. You can also touch **Settings** to set the playback mode and add background music.

### 7.5.1 Opening Photo

Touch **Photo** on the Applications screen to open it.

By default, pictures are sorted by date. You can touch a picture to display it in full screen mode.



If you have a great many pictures on your Tablet or microSD card, it may take a few minutes to discover and organize them when you open **Photo**.

### 7.5.2 Viewing a Picture

1. Touch a picture to view it in full-screen mode. When viewing a picture in full screen, flick left or right across the screen to view the previous or next picture.
2. Touch the screen to display the zoom control, with which you can zoom in or zoom out on the picture.

### 7.5.3 Sharing a Picture

When viewing a picture, touch it, and then touch . Touch the application you want to use to share a picture with your friends.

### 7.5.4 Rotating a Picture

To rotate a picture, touch the picture, and then touch .

## 8 Handy applications

### 8.1 Calendar

You can use the **Calendar** to create and manage events such as meetings and appointments. Touch **Calendar** on the Applications screen to open it. The current and following day's events are shown on the event widget on the Home screen.

### 8.2 Weather

The **Weather** application displays the weather forecast of your specified location. The weather information is summarized in the Weather widget on the Home screen and you can touch it to view more details. Touch the temperature scale icon to switch between Celsius and Fahrenheit as you want.

## 8.3 RSS Reader

The RSS Reader lists top news stories about common topics. The RSS Reader widget on your Home screen lists a category of top headlines, touch it to open a list of the top stories in the news and scroll to touch the category of news you are interested in.

## 8.4 Memo

Touch **Memo** on the Home screen or on the Applications screen to make text notes or drawing notes.

## 8.5 Alarm Clock

You can touch **Clock** on the Home screen or on the Applications screen to open a screen where you can set the alarm time and other attributes.

You can set an alarm by modifying an existing alarm or by adding a new one. Touch an existing alarm to set its time and other attributes. Or press the **Menu** key and touch **Add alarm** to add a new one.

Touch to make the check box to the left of an alarm checked or unchecked to turn the alarm on or off.

Touch and hold an alarm to delete it.

## 8.6 Calculator

Touch **Calculator** on the Home screen or on the Applications screen to open the calculator to solve math problems. You can drag to switch between basic and advanced panels, or press the **Menu** key and touch **Advanced panel**.

## 8.7 Documents

Touch **Documents To Go** on the Applications screen to view documents in common formats such as Word, Excel, PowerPoint and PDF.

## 8.8 File Manager

### 8.8.1 Creating a Folder

1. Touch **File Manager** on the Applications screen.
2. Press the **Menu** key on the **File Manager** screen, and then touch **New folder**.
3. Enter the new folder name in the text box.
4. Touch **Save** to confirm that you want to create the folder.

### 8.8.2 Deleting files and folders

You can delete a file or a folder by touching and holding it and touch **Delete** in the menu that opens. Alternatively you can delete files and folders by following these steps:

1. Press the **Menu** key on the **File Manager** screen.
2. Touch **Delete**, and touch files or folders you want to delete to make them checked.
3. Press the **Menu** key, and touch **Done**.
4. Touch **OK** on the dialog that opens to confirm that you want to delete the files or folders.

### 8.8.3 Searching a File

1. Press the **Menu** key on the **File Manager** screen, and then touch **Search**.
2. Enter the name or keyword of the name of the target file or folder in the search text box.
3. Touch **Search**. Your Tablet starts to search for the file or folder in all folders and subfolders.
4. The search result is shown in a list. Select the file or folder you want from the list then touch that entry to open your target file or folder.

## 9 Personal Information and Data Security

The use of some functions or third-party applications on your device could result in your personal information and data being lost or becoming accessible to others. Several measures are recommended to help you protect personal and confidential information.

- Place your device in a safe area to prevent it from unauthorized use.
- Set your device screen to lock and create a password or unlock pattern to open it.
- Periodically back up personal information kept on your SIM/UIM card, memory card, or stored in your device memory. If you change to a different device, be sure to move or delete any personal information on your old device.
- If you are worried about viruses when you receive messages or emails from a stranger, you can delete them without opening them.
- If you use your device to browse the Internet, avoid websites that might pose a security risk to avoid theft of your personal information.
- If you use services such as Wi-Fi tether or Bluetooth, set passwords for these services to prevent unauthorized access. When these services are not in use, turn them off.
- Install or upgrade device security software and regularly scan for viruses.
- Be sure to obtain third-party applications from a legitimate source. Downloaded third-party applications should be scanned for viruses.
- Install security software or patches released by Huawei or third-party application providers.
- Some applications require and transmit location information. As a result, a third-party may be able to share your location information.
- Your device may provide detection and diagnostic information to third-party application providers. Third party vendors use this information to improve their products and services.
- If you have concerns about the security of your personal information and data, please contact [mobile@huawei.com](mailto:mobile@huawei.com).

## 10 Legal Notice

**Copyright © Huawei Technologies Co., Ltd. 2011. All rights reserved.**

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

The product described in this manual may include copyrighted software of Huawei Technologies Co., Ltd. and possible licensors. Customers shall not in any manner reproduce, distribute, modify, decompile, disassemble, decrypt, extract, reverse engineer, lease, assign, or sublicense the said software, unless such restrictions are prohibited by applicable laws or such actions are approved by respective copyright holders.

### Trademarks and Permissions



**HUAWEI, HUAWEI**, and



are trademarks or registered trademarks of Huawei Technologies Co., Ltd.



**SRS**  
TruMedia

is a trademark of SRS Labs, Inc. TruMedia technology is incorporated under license from SRS Labs, Inc..

SRS TruMedia™, a feature-rich audio solutions tuned specifically for mobile devices, provides a cinema-like surround headphone performance with deep, rich bass.

HDMI, the HDMI Logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Other trademarks, product, service and company names mentioned are the property of their respective owners.

### Notice

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and therefore may not be activated or may

be limited by local network operators or network service providers. Thus the descriptions herein may not match exactly the product or its accessories you purchase.

Huawei Technologies Co., Ltd. reserves the right to change or modify any information or specifications contained in this manual without prior notice and without any liability.

### **Third-Party Software Statement**

Huawei Technologies Co., Ltd. does not own the intellectual property of the third-party software and applications that are delivered with this product. Therefore, Huawei Technologies Co., Ltd. will not provide any warranty of any kind for these third-party software and applications. Neither will Huawei Technologies Co., Ltd. provide support to customers who use these third-party software and applications, nor be responsible or liable for the functions of these third-party software and applications.

Third-party software and applications services may be interrupted or terminated at any time. Huawei Technologies Co., Ltd. does not guarantee that any content or service would be maintained for any period during its availability. Third-party service providers provide content and services through network or transmission tools outside of the control of Huawei Technologies Co., Ltd. To the greatest extent permitted by applicable law, it is explicitly stated that Huawei Technologies Co., Ltd. shall not compensate or be liable for services provided by third-party service providers, or the interruption or termination of third-party contents or services.

Huawei Technologies Co., Ltd. shall not be responsible for the legality, quality, or any other aspects of any software installed on this product, or for any uploaded or downloaded third-party works, such as texts, images, videos, or software. Customers shall bear the risk for any and all effects, including incompatibility between the software and this product, which result from installing software or uploading or downloading the third-party works.

This product uses the open-sourced Android operating system. Huawei Technologies Co., Ltd. has made necessary changes to the system. Therefore, this product may not support all the functions that are supported by the standard Android operating system or may be incompatible with third-party software. Huawei Technologies Co., Ltd. shall not be liable for any of such situation.

## **DISCLAIMER OF WARRANTIES**

THE CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.

## **LIMITATIONS OF LIABILITY**

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL HUAWEI TECHNOLOGIES CO., LTD. BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOST PROFITS, BUSINESS, REVENUE, DATA, GOODWILL OR ANTICIPATED SAVINGS.

THE MAXIMUM LIABILITY (THIS LIMITATION SHALL NOT APPLY TO LIABILITY FOR PERSONAL INJURY TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH A LIMITATION) OF HUAWEI TECHNOLOGIES CO., LTD. ARISING FROM THE USE OF THE PRODUCT DESCRIBED IN THIS DOCUMENT SHALL BE LIMITED TO THE AMOUNT PAID BY CUSTOMERS FOR THE PURCHASE OF THIS PRODUCT.

## **Import and Export Regulations**

Customers shall comply with all applicable export or import laws and regulations and be responsible to obtain all necessary governmental permits and licenses in order to export, re-export or import the product mentioned in this manual including the software and technical data therein.

Issue: 04 (2011-07-25)

Part Number: 903066



for Android™ Android is a trademark of Google Inc. Use of this trademark is subject to Google Permissions.