

S5

User's Manual



This guide is subject to change for product improvement without prior notice.



Thanks for purchasing viliv.
Please read the precautions
thoroughly before using the product.

viliv

Copyright

Yukyung Technologies Corp. has the copyright for this guide.

Contents of this manual may not be copied or produced in any form or means without prior authorization from Yukyung Technologies Corp.

©2009 Yukyung Technologies Corp. All rights reserved.

Certification

This device has acquired EMC certification for home use (Class B) and is designed not only for use in residential area but anywhere.



Grade B Device
(Broadcast Communication Device for Residential Area)

Registered Trademark

viliv is the registered trademark of Yukyung Technologies Corp.

Windows 2000, Windows XP and Windows CE are the registered trademarks of Microsoft Corporation.

Liability Disclaimer

Infringement of Intellectual Property Rights: Playing, copying or distributing any part or all of any copyrighted contents such as software, music or video with this device may infringe on a third party's legitimate intellectual property rights or violate copyright law. All legal responsibilities for the infringement of copyright or intellectual property rights from the use of this device lie with the user.

Improper Use: The manufacturer of this device is not liable for any damage or improper use and operation by using this device and infringement of copyright and portrait right by user when taking photos. In addition, the manufacturer is not liable for bodily injury or property damage that may occur arising from inappropriate use other than operation standards or conditions.

Data Loss: Any audio, video or photo files stored in this device may be deleted due to damage or operational error caused by user's careless handling or unknown failure or when the device undergoes warranty repair. Therefore, the files must be backed up in a separate place. In these cases, the manufacturer is not liable for the loss or damage of data stored in the device.

Specification Change: The standards, accessories, embedded software and manual contents of this device may be changed without user's prior consent or prior notice to the user.

Contents




Safety Precautions for Use	4
Names of Parts	7
Basic Components	7
Front View	8
Top View	9
Left/Right View	10
Rear View	11
Installation and Cable Connection	12
USB Data Link Connection.....	12
USB Connection	12
Separating/Attaching Battery	13
Separating Battery	13
Attaching Battery	13
Inserting/Extracting USIM Card	14
Basic Operation	15
Power On/Off.....	15
Setting/Cancelling Hold Function	15
Volume Control	16
Mute.....	16
Resetting	16
Jog and Function Buttons.....	17
Turning On/Off the LCD Screen	18
Touch Screen	18
Virtual Keyboard	18
Set Up for villv Manager	19
Using for the First Time	20
Using for the First Time	20
Recovery Solution (AMI Rescue) Guide	22
Way to Use Recovery Solution (AMI Rescue).....	22
Specifications	23
General Specifications	23

Safety Precautions for Use

The precautions below are provided to prevent bodily injury or property damage by using this product correctly. Please observe the precautions.

Precautions on Power



- Do not touch the power adapter with wet hands.
- Plug the power cord into an outlet with grounded jack.
- Be sure the plug goes in all the way and is not loose.
- Do not use your device if it is damaged, including an exposed or peeled power cord.
- If lightning occurs nearby or if you are absent for a long time, unplug the plug from the outlet.

Precautions on Battery



- Do not apply strong impacts or make a hole with a sharp object.
- Do not leave the battery in a hot place such as sauna or bathroom or otherwise heat it.
- Do not let the battery become wet or immersed in liquid.
- Do not allow children or pets to bite or suck the battery.
- Keep the battery charging port away from metals.
- When disposing of the battery, do not burn it or throw it away in domestic trash. Dispose of the battery at the nearest disposal place for batteries after contacting your local water disposal agency.

Precautions for the Device



- Avoid exposing to direct sunlight and do not leave in a closed car.
- Do not leave the device in a dusty place or a humid place such as a bathroom.
- Keep the device away from credit cards, bankbooks, or a communication ticket.
- Do not use accessories that are not provided with this device.
- Do not touch the LCD screen with a sharp object.

Precautions in Use



- Do not listen to music at a high volume for a long time.
- Do not watch the video for too long a time.
- Do not use headphones/earphones while driving, walking or using public transport.
- Do not apply strong impacts on the LCD.
- If the device begins to smoke or become deformed by heating, stop using it immediately and contact your nearest Customer Service.
- Do not use the device in a hospital, on board a plane or while driving.
- Do not directly put and use the device frame or the power adapter on your bare skin for a long time. The temperature of the station may rise even during normal operation. If you continue to use the device on your bare skin (in particular, when the adapter is connected), you may feel uncomfortable or receive a burn.

Other Precautions



- If the device is wet, do NOT turn on the power. Separate the battery and wipe it with a soft dry cloth. After that, contact Customer Service.
- When cleaning the device, wipe it with a soft dry cloth and do NOT use chemicals, such as benzene or thinner.
- Do not repair, disassemble or alter in any manner.
- Do not allow any liquid or foreign materials to get inside the device.
- Do not drop the device.

Warning | Please observe the instructions below. Failure to do may cause heating, fire, explosion, etc.

- If the battery can be seen to be swollen, there may be imminent danger. Immediately contact the manufacturer or sales representative.
- Only use an eligible specified charger.
- Keep the device away from open flames. (Do not put it in a microwave.)
- Do not leave the device in a car in summer.
- Do not store or use the device in a hot and wet place like a bathroom.
- Do not put the device on bedclothes, electric mattress or carpet and use it for a long time.
- Do not store the device powered on in a closed space.
- Do not allow metal products, such as a necklace, coil, key or watch, to touch the battery port.
- Use a lithium secondary battery guaranteed by a portable device manufacturer.
- Do not disassemble or pierce the device and do not apply excessive strength.
- Do not apply excessive impact like dropping the device from a high place.
- Do not expose the device to high temperatures of 60°C or higher.
- Avoid humidity.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received. Including interference that may cause undesired operation.

Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ tv technician for help.

FCC RF Exposure Information

In August 1996 the Federal Communications Commission(FCC) of the United States with its action in Report and order 96-326 adopted an updated safety standard for human exposure the ra-dio frequency electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of 'S5' complies with the FCC guidelines and those international standards. Use only the supplied or an approved antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage your 'S5', or result in violation of FCC regulations.

'S5' was tested for typical body-worn operation using the optional belt-clip / holster placed touch(0cm) from the body. The use of non-tested accessories or other body-worn operations may not comply with FCC exposure requirements and should be avoided.

Safety Precautions for Use

The device functions vary depending on model.

Read the relevant precautions for the provided function before using the device.

Precautions for GPS



- When initially operating this device, it is recommended you warm it up for over 15 minutes under a clear open sky and open area.
- If the vehicle equipped with this device is not used for 7 days or longer, the data storage recharger inside the GPS may be discharged and require warming up time of over 15 minutes.
- GPS signals are high frequencies around 1575 MHz so they may be affected by bad weather, such as rain and fog, and electromagnetic interference and the reception rate of the GPS may deteriorate.
- When the GPS receiver is under an elevated road, inside a tunnel, in a densely built-up area or near a high-voltage line, it is difficult to receive radio waves so GPS reception may fail.
- The GPS receiver may not work normally in some vehicles with UV coating, sun-block coating or electromagnetic interference.
- The operational temperature of the GPS receiver is between 0°C and 50°C. Problems may occur in midsummer or severe winter so maintain an appropriate temperature.
- On some roads running parallel to a driveway or an elevated road, the information on speed limits or dangerous sections for speeding may not be accurate.

Precautions for the Bluetooth



- Do not attempt to operate the Bluetooth while driving. Accidents caused by such improper handling are the sole responsibility of driver.
- To prevent electromagnetic problems or other dangers, turn off the Bluetooth setting wherever the use of Bluetooth is inhibited.
- If you use a certain medical device, such as a pacemaker or a hearing aid, ask the manufacturer of the relevant device if it is correctly cut off from energy sources before using it. If necessary, you may ask for some assistance from your regular doctor.
- This device satisfies Bluetooth standards 2.0. Some Bluetooth devices may not be fully compatible with this device. For detailed information on compatibility, contact the manufacturer of the relevant device or our Customer Service.
- This wireless equipment may experience electromagnetic interference, so it is not permitted for use by a life-saving service.

Precautions for Navigation




- Placing the device where it blocks the driver's view or is within the driver's operation range for driving may cause an accident. Adjust the volume to an appropriate level so that it does not disturb while driving.
- Fix the device rack onto the windshield securely so that it will not fall or move while driving.
- If the rack is attached onto the windshield for a long time, its adhesion may become weak and it may fall. Therefore, if you are not going to use the device for a long time, separate it and keep in a safe place.
- Do not disassemble and attach it inside a vehicle in any manner. To do so may affect the electrical system and GPS reception sensitivity and lead to a fire.
- Do not separate the cigar jack from the vehicle while using the device. To do so may cause a malfunction.
- Set the device up where it does not block the driver's view or is not in the way of the airbag's operation.

WiFi and 3G Modem (or HSDPA, HSUPA) do not operate simultaneously.


Names of Parts

The appearance of the components below may differ from the actual components and some components are subject to change.

Basic Components




Main Body




Standard Removable Battery



A Hand Strap and a Stylus Pen in One



AC/DC Power Adapter




Earphone



User's Manual


Front View



- 1 Built-in Speakers** Stereo speakers are built in.
- 2 Jog Dial**
Dial to Move Up/Down/Left/Right (▲/▼/◀/▶) To move Up/Down/Left/Right on screen.
(If it is pressed, continuous movement occurs on the screen.)


Tab Button (⊙) When pressed, the status bar appears.
- 3 Menu Button** Displays the menu.
- 4 IR Receiver** Used when the wireless remote control is used.
- 5 OK (Run) Button**
With a Quick Click The selected menu item or the icon function is executed.
When Pressed for a Bit Longer The LCD comes on or goes off.
- 6 Right-Click Button** Displays the properties.
(the same function as the right-click of a PC mouse.)
- 7 Shortcut Button** The initial value is set to the virtual keyboard.
User can make shortcuts to programs.
* Same as pressing Ctrl+Alt+h at the same time on a keyboard.
* For detailed information how to make shortcuts, refer to the detailed User's guide.
- 8 TFT LCD/Touch Screen** User can operate the device on the touch screen.

Top View



- 1 Heat Emission Hole** Emits heat generated by the device.
 * If the heat emission hole is blocked, the device can overheat, which can be dangerous. Take care not to allow this to be blocked.
 * Take care not to allow water into this hole.
- 2 Earphone Jack** Connect the earphone or speakers through this.
- 3 Volume Button** - Adjust the volume with this.
 Pressing the center of the volume button turns on the Mute function.
- 4 Built-in 3G Antenna** 3G Modem antenna. (3G Model only)


Left/Right View



- 1 **Reset Button** Pressing this with a pointed object turn off the device.
- 2 **Multi-I/O Jack** Used for Component/ S-VIDEO output.
- 3 **USB Host Jack** Used to connect an external device to the device through USB connection.
- 4 **USB Link Jack** Used to connect the device to a computer. (It will work as an external storage device.)
This port is for advanced users only. Other users are not recommended to use this feature because it may not work properly with a regular USB cable. We recommend you to use the data link cable for PC to PC connection instead.
- 5 **Power Adapter Jack** Used when connecting a power adapter to the advice or when recharging the battery.
- 6 **Power Indicator** Displays the battery status. (When charging: red; when fully charged: blue)
- 7 **Battery Separation/Lock** Separates/ Holds in the battery.
- 8 **Power/Lock Switch** Used when locking the power on / off (locking all the functions) status.

Rear View

The figure below shows the rear side of the main body without the battery. (Refer to Page 13 for Separating/Attaching battery.)




- ① **Battery Recharging Contact** Battery jack's contact area.
- ② **Separating/Attaching Battery** Push the battery downward to separate the battery, as shown in the figure above.
- ③ **USIM Card Slot (Optional)** USIM card insertion slot. (Refer to page 14 for USIM card insertion/separation.)
- ④ **Battery**

Installation and Cable Connection

The connections of external devices may vary in accordance with products.


USB Data Link Connection

A USB cable is connected to the USB Data Link port on the right side of the station.



USB Connection


This is used for the connection of external devices, such as digital camera, external HDD, etc.



Separating · Attaching Battery

Separating Battery

Turn the battery separation/placement button on the right side of the device toward open as in the illustration below. Then, separate the battery.




Notice

- Separate the charger after turning the power of the station off.
- If not, you may receive an electric shock by a short circuit in the battery power part.

Attaching Battery

Adjust the battery into the groove as in the illustration below, and press it until it clicks.




Notice

- If the battery is misaligned with the groove and you attempt to mount the battery, the device may be damaged.

Inserting · Extracting USIM Card

How to Insert ↑ : Let the front of a USIM card face the USIM card slot and then push it in the arrow direction until a click sound is heard. (If, however, you push the USIM card using too much force, the card may be damaged.)

How to Extract ↓ : Since this device adopts a one-touch method, you may gently press on the end of the USIM card to extract it automatically. (Pull out the USIM card slightly protruded.)



Notice

- Please, turn the power of the station off before inserting or extracting the USIM card.

Power On/Off



Turning the Power On

With the power off, push the power button on the right side of the device up to turn it on.

- ▷ The main screen displays on the LCD screen.



Turning the Power Off

From the On position, push the power button on the right side of the device up all the way to turn it off.

Setting/Cancelling Hold Function



Setting the Hold Function

Push down the Hold button on the right side of the device.

- ▷ Once it is set to Hold, none of the buttons including the touch screen functions will work except for the Hold button.




Cancelling the Hold Function

Push up the Hold button on the right side of the device to the middle.

- ▷ Once the Hold setting is cancelled, all of the buttons, including the touch screen functions, will work.


Volume Control



Volume Control

Adjust volume by pressing the **VOL** button on the upper area of the device.

Mute




Mute

Press the middle of the **VOL** button on the upper area of the device.

▷ The Mute function is on.

Resetting

Use the Reset button if the touch screen and/or the buttons on the device do not work.



Reset

Lightly press the **Reset** button on the left side of the device with the Touch Pen.

Jog and Function Buttons

The Jog key has different functions in accordance with the program functions.



Up↑/Down↓/Left←/Right→ Move (○/○/○/○)

This is the button to move in Up↑/Down↓/Left←/Right→ direction on screen.



Selection (Center Key of the Direction Keys)

Enter button



MENU

It is used to move to the main menu.



OK

If pressed shortly - Execute the selected menu or left-click the mouse.
If pressed for a long time - Turn on/off LCD screen. (It doesn't operate on mouse function mode.)



C

Right - clicking mouse function



Virtual Keyboard

User-defined button (Initial value: Execution of virtual keyboard)



MENU + Vol -, +

Brightness control



Mouse function: Press Menu button for a **long** time. (Job button can be used for mouse function.)

It operates as 4-way mouse function. If the menu is pressed for a long time again, it operates as the arrow key.



Rotation of Screen (Pivot)

The applications screen that doesn't consider pivot can be shown by omitting some parts or in a strange way depending on the status of pivot.



Utility manager

Turning On/Off the LCD Screen



Turning Off the LCD Screen

When it is on, press and hold the **OK** button, then the screen goes off.

Turning On the LCD Screen

When it is off, press and hold the **OK** button, then the screen comes on.

Touch Screen



Touch

Click any place on the LCD screen with the Touch Pen.

▷ If you keep it pressed, it will work like a right click.

Double Touch

This works the same way as the double-click with a PC mouse. Just double-touch any place on the LCD screen.

Drag

With the Touch Pen, press any place on the screen and drag it to the final destination on the screen.

▷ It works the same way as dragging with a PC mouse.

Virtual Keyboard



Running the Virtual Keyboard

Click the **vilivSoftKeyboard** icon on the screen to run the Virtual Keyboard.

(You can also press the  button.)

Hiding the Virtual Keyboard

Clicking the **Hide** icon on the virtual keyboard will minimize the virtual keyboard into the  icon.


▷ Pressing the  icon brings it back to its original form.

Ending the Virtual Keyboard

Right-click the  icon on the task bar and select **Exit**.

Set Up for viliv Manager

viliv Manager is executed by double touching vilivManager on the screen.



- 1 **Wireless LAN Power**
Turn on/off self-powered wireless LAN function.
- 2 **Bluetooth Power**
Turn on/off self-powered Bluetooth function.
- 3 **3G Modem Power (3G Model only)**
Turn on/off self-powered 3G Modem function.
- 4 **Windows Start Option**
 1. OFF: Always start with OFF status.
 2. Last Status: Start with the last status.
 3. ON: Always start with ON status.
- 5 **Brightness of LCD**
Adjust by status bar or -, + button.
- 6 **Setting Vibration**
 1. No Use: Do not use vibration function.
 2. When using soft keyboard: Operate only if soft keyboard is used.
 3. Always Use: Operates when operating for all touches.
- 7 **Set Up for Windows Start Program**
 1. Set whether or not to execute Cube UI automatically.
 2. Set whether or not to execute viliv Manager automatically.

Using for the First Time



4 The screen related to automatic update appears. After the selection, click **next**.



5 The screen to assign the computer name appears. To do this, an external keyboard is needed. If you don't have an external keyboard, you can click **next** to assign the computer name, or you can open the video keyboard on Microsoft Utility Manager by pressing the menu button of the product and the user registration button of  shape on the lower-right corner simultaneously to enter the computer name. Microsoft video keyboard may not support the input of Korean letters. If you want to assign the computer name later, you can assign in computer control panel → **system registration information** → **computer name**.

It may take a couple of minutes. Please wait for a moment.



6 The screen asking "Do you want to register on the internet?" appears. After selecting **Yes** or **No**, click **next**.

7 The screen showing completion of the installation process appears. Click **next**.

8 The installation of Microsoft Windows XP Home is complete. Please wait for a moment. The screen for Windows wallpaper will appear shortly.

Recovery Solution (AMI Rescue) Guide

As an image-based OS recovery solution, it recovers to the initial status of shipment from factory when HDD of user cannot be booted from OS or it has problems.

Way to Use Recovery Solution (AMI Rescue)



1 Execution of Recovery Solution (AMI Rescue)

If viliv logo appears when booting the system (BIOS POST), press the select button of product's jog key 1-2 times or F10 key if external keyboard is connected.


▷ As the logo disappears, Pre-Boot Menu window appears.



2 Pre-Boot Menu

When selecting Normal Boot, booting proceeds to Windows. For recovering OS, select AMI Rescue and click Launch Service.

▷ AMI Rescue Lite-Wizard appears.



3 AMI Rescue Lite-Wizard

When clicking **Restore OS** button, a message that confirms the recovery of OS is displayed. If you press **Yes (Y)**, it starts the recovery of OS.

If the process of OS recovery is completed, a message that confirms the successful recovery is displayed. (Partition 0 on disk 0 was successfully restored.)

If you press **OK** button, the system is booted again automatically.

▷ Now, if you boot to Windows, OS will be in the initial status of shipment from factory.

Notice

- When recovering OS, recover by connecting battery adaptor.
- Since data is deleted in case of recovery, make sure to back up the data beforehand.
- Please wait for 20 sec when black screen is showing to prepare boot up the Windows VISTA.
- It will take a time more for Windows VISTA Users.



Specifications

The device specifications below may be changed without prior notice for performance improvement.

General Specifications

Product Name	S5
CPU & Chipset	Intel® Atom™ 1.33GHz (Z520) + SCH US15W
LCD	4.8" WSVGA (1024 x 600)
RAM	1GB
Storage	HDD 60GB / SSD 32GB / SSD 64GB
WWAN (Optional)	WiMAX; HSDPA
LAN	IEEE 802.11b/g
Bluetooth	Bluetooth Ver2.0 + EDR
GPS (Optional)	SiRF Star III
Connector	Audio x1, USB x1, USB (Link) x1, Multi I/O for cradle x1
Audio	Stereo speakers
Battery	Lithium Polymer (Slip On/Off Type) Voltage : 3.7V Capacity : 6,200mAh
Dimension	154 (W) x 84 (H) x 24.4 (T) mm
OS	Windows XP Home
Operation Temperature	0°C ~ 40°C



Memo

viliv